

SCH-a930 Series

P O R T A B L E

A l l D i g i t a l

M o b i l e P h o n e

User Guide

**Please read this manual before operating your
phone, and keep it for future reference.**



Intellectual Property

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating there to (the “Phone System”), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

Samsung Telecommunications America (STA), L.P.

Headquarters:

1301 E. Lookout Drive

Richardson, TX 75082

Customer Care Center:

1000 Klein St.

Plano, TX 75074

Toll Free Tel: 1.888.987.HELP (4357)

Fax: 972.801.6065

Internet Address: <http://www.samsungusa.com>

©2006 Samsung Telecommunications America, L.P. is a registered trademark of Samsung Electronics America, Inc. and its related entities.

Licensed by Qualcomm Incorporated under one or more of the following patents: U.S. Patent No. 4,901,307; 5,056,109; 5,099,204; 5,101,501; 5,103,459; 5,107,225; 5,109,390.

Printed in Korea

GH68-07489A

Openwave® is a registered Trademark of Openwave, Inc.

RSA® is a registered Trademark of RSA Security, Inc.

VibeTonz® is a registered Trademark of Immersion Corporation.

Disclaimer of Warranties; Exclusion of Liability

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS", AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

Table of Contents

Section 1: Getting Started	9
Turning Your Phone On and Off	10
Setting Up Voicemail	10
Understanding this User Manual	11
Section 2: Understanding Your Phone	13
Features of Your Phone	14
Front View of Your Phone	15
Command Keys	19
Understanding the Display Screen	21
Battery	26
Removable Memory Card Storage	29
Phone Memory Storage	29
Section 3: Call Functions	31
Making a Call	32
Answering a Call	33
Recent Calls	33
Roaming	37
TTY	38
VoiceSignal™	39
Section 4: Menu Navigation	51
Menu Navigation	52
Menu Outline	54
Section 5: Entering Text	61
Changing the Text Entry Mode	62
Using Word Mode	63
Entering Upper and Lower Case	64
Entering Symbols	65
Entering Numbers	66

Section 6: Understanding Your Contacts 67

Opening Contacts Menu	68
Adding a Contact	69
Adding Pauses	72
Contact Groups	73
Finding a Contacts Entry	76
Editing an Existing Contact Entry	77
Deleting a Contact Entry	77
Storing Numbers After a Call	78
Speed Dialing	78
My Name Card	80
Finding My Phone Number	80

Section 7: Messaging 81

Types of Messages	82
Retrieving New Messages	82
Creating and Sending TXT Messages	83
Creating and Sending PIX/FLIX Messages	85
Receiving PIX/FLIX Messages	87
New Sketch Messages	89
Message Folders	89
Changing Message Settings	95
Voicemail	96
E-Mail	97
Mobile IM	98
Chat	99

Section 8: Changing Your Settings 101

My Account	102
Tools	102
Sounds Settings	103
Display Settings	106
Phone Settings	111
Call Settings	119

Bluetooth	123
Memory	126
Phone Info	127
Section 9: Multimedia	129
Get It Now	130
Get Tunes & Tones	131
Get PIX & FLIX	142
Get Fun & Games	151
Get News & Info	152
Get Going	153
Get Extras	153
Section 10: Tools	155
Voice Commands	156
Calculator	156
Calendar	158
Alarm Clock	161
World Clock	163
Stop Watch	164
Notepad	165
Section 11: Mobile Web	167
Mobile Web	168
Launching Mobile Web	168
Exit Mobile Web	168
Navigate the Web	169
Mobile Web Soft Keys	169
Links	171
Place a Call While Using Mobile Web	171
Section 12: Health and Safety Information	173
Health and Safety Information	174
Consumer Information on Wireless Phones	177
Road Safety	186
Operating Environment	189

Using Your Phone Near Other Electronic Devices	190
Potentially Explosive Environments	192
Emergency Calls	193
FCC Notice and Cautions	194
Other Important Safety Information	195
Product Performance	196
Availability of Various Features/Ring Tones	197
Battery Standby and Talk Time	198
Battery Precautions	198
Care and Maintenance	200
Section 13: Warranty Information	203
Standard Limited Warranty	204
Index	211

Section 1: Getting Started

Topics Covered

- Turning Your Phone On and Off
 - Setting Up Voicemail
 - Understanding this User Manual
-

This section allows you to start using your phone by activating your service, setting up your voicemail, contacting customer support, or getting an understanding of how this manual is put together.

Turning Your Phone On and Off

Turning Your Phone On

1. Open the flip, then press .

Note: As with any other radio-transmitting device, do not touch the internal antenna as it affects call quality and may cause the phone to operate at a higher power level than is necessary. The internal antenna is located along the top on the back side of your phone.

2. Your service provider's name momentarily appears in the display and the phone begins searching for a network signal.
3. Once the phone finds a signal, the time, date, and day appear in the display.
4. You're now ready to place and receive calls.

If the phone is outside the Verizon Wireless coverage area the roaming icon  appears in the top of the display.

Turn Your Phone Off

Press and hold  for two or more seconds. Your phone powers off.

Setting Up Voicemail

Voicemail allows callers to leave voice messages, which can be retrieved any time.

Note: Once your voicemail account has been set up, you can use the Voicemail selection 7 (under the Messaging menu) to view details of voice messages in your voicemail box.

Voicemail Setup

1. In standby mode, press and hold the  key or press , , , .
2. Follow the prompts in the new user tutorial to setup your mailbox.

Listen to Voicemail

1. In standby mode, press and hold the  key or press , , , .
2. You are then prompted to enter your password followed by  key.
3. Follow the recorded prompts to listen to messages, change administrative options, and so on.

Understanding this User Manual

The chapters of this manual generally follow the same order as the menus and sub-menus in your phone. A robust index for quick reference to most features begins on page 211.

Also included is important safety information that you should know before using your phone. Most of this information is near the back of the guide, beginning on page 173.

Notes and Tips

Throughout this guide are icons and text that are set apart from the rest. These are intended to point out important information, quick methods for activating features, to define terms, and more. The definitions for these methods are as follows:

- **Notes:** Explain alternative options within the current feature, menu, or sub-menu.
- **Tips:** Provide quick or innovative methods for performing functions related to the subject at hand.
- **Important:** Points out important information about the current feature that could affect performance, or even damage your phone.

Section 2: Understanding Your Phone

Topics Covered

- Features of Your Phone
 - Front View of Your Phone
 - Command Keys
 - Understanding the Display Screen
 - Battery
 - Removable Memory Card Storage
 - Phone Memory Storage
-

This section outlines some key features of your phone. It also displays the screen and the icons that are displayed when the phone is in use.

Features of Your Phone

- Domestic and international voice and text messaging service (available on participating networks).
- High speed data (CDMA 2000 1x Technology)
- EVDO 1x Technology
- Global Positioning (GPS) Technology
- PIM Functions
- MMS Messaging
- TXT Messaging
- PIX Messaging
- FLIX Messaging
- E-mail Messaging
- Mobile IM
- Chat
- 1.3 Mega Pixel Camera
- Camcorder
- Advance Speech Recognition
- Speakerphone
- microSD™/TransFlash™ Memory Card Slot
- Phone Memory Storage
- Music Player
- Bluetooth® Wireless Technology **
- VibeTonz®

**The SCH-a930 supports the following Bluetooth profiles: Headset, Handsfree, Serial Port and Dial Up Networking. The SCH-a930 does not support Bluetooth OBEX profiles. Go to www.verizonwireless.com/bluetoothchart to check vehicle/accessory compatibility.

Front View of Your Phone

The following illustrations show the main elements of your phone:

Open View



Features

1. **Earpiece:** The earpiece allows you to hear the other caller.
2. **Internal LCD:** Displays all the information needed to operate your phone.
3. **Navigation Keys:** This key allows you to scroll through the phone menu options.
4. **Left Soft Key Option:** This key is used to navigate through menus and applications by selecting the choice available in the Left Soft key Option.
5. **Camera/Camcorder Key:** This key allows you to activate the camera. Press and hold to activate the camcorder.
6. **Send Key:** Allows you to place or receive a call. In standby mode, press the key once to access the recent call log.
7. **Clear Key:** Deletes characters from the display when you are in text entry mode. Press to return to the previous menu or screen when navigating features on your phone.
8. **Special Function Keys:** Enters special characters. Performs various functions.
9. **Power/Accessory Connector:** The power/accessory interface connector is used to plug in the charging accessories and also connect any available accessory cables to your phone.
10. **Microphone:** The Microphone allows the other caller to hear you clearly when you are speaking to them.

- 11.** Alpha-numeric Keys: Use these keys to enter numbers, letters, and characters.
- 12.** End Key: Ends a call. If you press and hold the END key, the power goes On or Off. When you receive an incoming call, press to mute the ringer and send the call to voicemail.
- 13.** Speech Recognition Key: Press to activate Voice Signal.
- 14.** Center/OK Key: Pressing when navigating through a menu accepts the highlighted choice in a menu.
- 15.** Right Soft Key: This key is used to navigate through menus and applications by selecting the choice available in the Right Soft key Option.
- 16.** Headset Jack: Allows you to plug in an optional headset for safe, convenient conversations.

Closed View



Features

- 1. Volume Key:** Allows you to adjust the master volume in standby mode (with the flip open) or adjust the voice volume during a call. To mute the ringer during an incoming call, press the volume key up or down. When the flip is closed, press and hold the key, and sub LCD displays.
- 2. External LCD Display:** External LCD shows signal and battery strength, time, day, and date. It also displays incoming calls or messages.

3. **Speakerphone Key:** Press this key to enable/disable the speakerphone option.
4. **Rewind Key:** Music rewind key.
5. **Play/Pause Key:** Music play or pause key.
6. **Fast Forward Key:** Music fast forward key.
7. **Speaker:** Music, Ringtones, and Sounds are played through the speaker.
8. **microSD™/TransFlash™ Card Slot:** This expansion slot allows you to insert a microSD™/TransFlash™ memory card to add additional memory and storage capacity.
9. **Flash:** The built-in flash has manual and automatic capabilities.
10. **Rotating Camera Lens:** The lens of your built-in camera/camcorder.

Command Keys

Functions for the soft keys are defined by what appears above each in the display. There are two soft keys, the left soft key  and the right soft key .

Left Soft Key

Some functions of the left soft key are as follows.

- In standby mode, press the **Message** (left) soft key  to open the Message menu.
- When the left soft key function is Settings, press the **Settings** (left) soft key  to view settings for the feature.

- When the left soft key function is Edit, press the **Edit** (left) soft key  to edit a Contact or Profile setting.

Right Soft Key

Some functions of the right soft key are as follows.

- In standby mode, press the **Contacts** (right) soft key  to open your Contacts list.
- When the right soft key function is **Options**, press the **Options** (right) soft key  to view more options for the current menu.

Clear Key

The **CLR** key  is used to erase or clear numbers, text, or symbols from the display. You can also use  to return to a previous menu or to return to standby mode from any menu.

1. If you enter an incorrect character, briefly press  to backspace (and delete) the character.
2. To erase the previous word in a sentence, press and hold  .
3. To back up one menu level, briefly press  .
4. To return to standby mode from any menu, press and hold  until you return to standby mode.

End Key

1. Press and hold the **End** key  to turn your phone on or off.
2. Briefly press  once to disconnect a call.
3. Press  to return to standby mode from any menu, or to cancel the last input.

Send Key

The **Send** key  is used to answer calls, dial calls, and to recall the last number(s) dialed, received, or missed.

1. Press  once to answer calls.
2. Enter a number and briefly press  to make a call.
3. Briefly press  in standby mode to display a list of recent calls to and from your phone.
4. Press  twice in standby mode to call the most recently dialed, received, or missed number.
5. Press  to pick up a waiting call. Press  again to switch back to the other call.

Navigation Key



Use the directional keys on the navigation key to browse menus, sub-menus, and lists. Each key also acts as a shortcut to launch applications. The down navigation key is user-definable.

Speakerphone Key



Use the speakerphone key  to switch from using the earpiece to the speakerphone before or during a call. Use the volume keys (located on the left side of your phone) adjust the volume. Press the speakerphone key to enable and disable the speakerphone option.

Understanding the Display Screen

The display is reserved for icons that indicate network status, battery power, signal strength, and more. The following table lists some display icons and their descriptions.

Display icons



Signal Strength: Always appears when your phone is on and indicates the current signal strength. More bars indicate a stronger signal.



Standalone Mode: Appears when Standalone Mode is on. When on, all RF functions for your phone are disabled, and you cannot use your phone to place or receive calls.



Roaming Indicator: Your phone is outside your home area. While roaming, another wireless provider may be handling your call. The service rate for the call may be higher than those made from within your home area. Please refer to Verizon Wireless for roaming rates.



Digital: Appears when your phone is receiving digital data.



1X Protocol: Indicates your phone is using the CDMA 1X protocol.



EVDO: Appears when your phone is using the EVDO protocol.



EVDO/1X: The EVDO/1X protocol is capable of high-speed broadband data (3G).

Note: 1X protocol is available only in the Verizon Wireless network.



EVDO/2G: Indicates your phone is using the EVDO 2G protocol.



SSL: Indicates the secure socket layer is active transmits your communications over the internet in an encrypted format.

-  **Voice Privacy:** Prevents eavesdropping over a CDMA traffic channel.
-  **No service indicator:** Your phone cannot find a signal because you're outside a service area. You cannot make or receive calls. Wait for a signal or move to an open area to find a signal. This indicator always appears when you first turn on your phone and disappears once service is located.
-  **Dormant:** Indicates no incoming or outgoing data.
-  **Voice Call:** Indicates a call in progress. When dialing a number, this icon flashes until the call connects.
-  **Data Call:** Indicates a call in progress. When dialing a number, this icon flashes until the call connects.
-  **E911:** Global Positioning Service (GPS) for 911 is set to On for emergency calls only.
-  **Location On:** Global Positioning Service is set to On for location and 911 calls.
-  **Bluetooth:** Indicates that Bluetooth wireless technology is active.
-  **Bluetooth Connected:** Indicates Bluetooth wireless technology is active and connected.
-  **Battery Level:** More bars indicate a greater charge. When the battery is low, an empty battery icon flashes and the phone sounds an alert, which indicates your phone is about to shut down.
-  **TTY:** Indicates that TTY is enabled.



All Sounds Off: The ringer is silenced for all alerts, incoming calls, and incoming messages. The phone alerts you by a flashing service LED.



Alarm Only: Your phone will only ring when the set alarm sounds.



Vibrate Only: Your phone vibrates upon receiving a call.



Speakerphone: Your phone switches to speakerphone instead of earpiece.



Missed Calls: Your phone displays this icon when calls are missed.



New Message: You've received a new text, page or web alert message. You're also notified of a new message by animations and sound. You have one or more unread voicemail messages in your voicemail box. (Only applicable on Verizon Wireless Network.)



Calendar Appointment: Your phone displays this icon when you have a calendar appointment scheduled.



Voicemail: You've received a voicemail message, page or web alert message.



Alarm On: Indicates that your phone has a set alarm.



Auto Answer: Automatic answer is enabled. Your phone automatically picks up calls after the designated time with hands-free car kit connected, stereo headset or when your bluetooth headset or bluetooth hands-free car kit is connected.

Dialogue boxes

Dialogue boxes prompt for action, inform you of status, or warn of situations such as low memory. Dialogue boxes and their definitions are outlined below.

- **Choice**
 - Example: "Save message draft?"
- **Reconfirm**
 - Example: "Delete all received messages?"
- **Performing**
 - Example: "Sending..." "Connecting..."
- **Completed**
 - Example: "Message sent successfully!"
- **Information**
 - Example: "New Message"
- **Error**
 - Example: "System Error!"
- **Warning**
 - Example: "Battery Low," "Memory Full!"

Battery

Note: This phone comes packaged with a partially charged rechargeable standard Li-Ion battery and travel charger.

Important: Although the phone can be used while the battery is charging, the battery must be fully charged before first use, otherwise you could damage the battery.

Using A Non-Supported Battery

Samsung handsets do not support the use of a non-supported battery.

When using a non-supported battery you will hear a series of beeps and you will see a warning message that indicates “NON SUPPORTED BATTERY SEE USER GUIDE.” If you receive this warning, battery charging has been disabled.



Samsung charging accessories (i.e. travel adapter, and cigarette lighter adapter) will only charge a Samsung approved battery.


To continue use of your Samsung handset press .

Note: When using a non-supported battery the handset can only be used for the duration of the life of the battery and cannot be recharged.

Important: Using a non-supported battery may cause damage to your phone. Use a Samsung supported battery only.


Install the Battery

1. Slide the battery cover down and lift up to remove it.
2. Insert the top end of the battery in the direction of the arrow printed on the battery into the phone housing. The gold contacts on the top of the battery should match up with those on the phone.
3. Push the bottom end of the battery down until it snaps into place.
4. Slide the battery cover up until it snaps into place.



Remove the Battery

1. Slide the battery cover down and lift up to remove it.
2. Use your finger to lift the battery (bottom end first) up and away from the phone.



Charge the Battery

Your phone is powered by a rechargeable standard Li-ion battery. Only use Samsung-approved charging devices and batteries. Samsung accessories are designed to maximize battery life. Using other accessories may invalidate your warranty and may cause damage.

Travel Charger

The travel charger is a convenient, light-weight charger that rapidly charges your phone from any 120 / 220 VAC outlet.

1. Plug the large end of the travel charger into a standard 120/220 VAC wall outlet.
2. Insert the smaller end of the travel charger into the charger/ accessory connector at the bottom end of the phone.



Note: You can use your phone while charging, however, the battery charges faster if the phone is turned off.

Battery Indicator

The battery indicator  in the upper-right corner of the display indicates battery power level. Four bars indicate a full charge, while an empty icon  indicates an almost empty battery. Two to three minutes before the battery becomes too low to operate, a blinking empty battery icon

 appears and a tone sounds. If you continue to operate the phone without charging, it shuts down.

Removable Memory Card Storage

Note: Your phone does not come with the microSD™/TransFlash™ memory card, it must be purchased as an accessory. See your service provider for more information.

The following file types can be saved to the removable microSD™ / TransFlash™ memory card:

- **My PIX:** Pictures you have saved from a PIX message or taken using your phone.
- **My FLIX:** Video Clips you have saved from a FLIX message or taken using your phone.
- **My Music:** Music you have downloaded directly from the V CAST Music catalog or music you have transferred from your PC using Sync Music.
- **My Sounds:** Sounds you have recorded using your phone or saved from a PIX message with Sound attached.

Phone Memory Storage

The following file types can be saved to the phone memory storage area:

- **My PIX:** Pictures you have saved from a PIX message, downloaded via the “Get It Now” application, or taken using your phone.
- **My FLIX:** Video Clips you have saved from a FLIX message, downloaded via the “Get It Now” application, or taken using your phone.
- **My Ringtones:** Ringtones you have downloaded via the “Get It Now” application, or saved from a PIX message with Ringtone attached.

- **My Music:** Music you have downloaded directly from the V CAST Music catalog or music you have transferred from your PC using Sync Music.
- **My Sounds:** Sounds you have downloaded, recorded using your phone, or saved from a PIX message with Sound attached.

Section 3: Call Functions

Topics Covered

- Making a Call
 - Answering a Call
 - Recent Calls
 - Roaming
 - TTY
 - VoiceSignal®
-

This section allows you to make or answer a call. It also includes the features and functionality associated with making or answering a call.

Making a Call

1. At the standby screen, enter the number you want to call using the keypad.
2. Press .

Making Calls Using Contacts

Contacts are entries that you create to store names, numbers, and other information for people or groups of interest. If you've already entered information into your Contacts list, you can recall and dial the contact easily. See "Adding a Contact" on page 69 for information on creating contacts.

1. At the standby screen, press the right soft key  **Contacts**.
2. Press the ▲ or ▼ keys on the side of your phone or the navigation up and down keys until the contact that you want to call is highlighted.

Tip: To quickly locate a name, press (or multi-press) any key on the keypad that corresponds to the first, second, and/or third letters of the contact's name.

3. When the desired contact is highlighted, press  **VIEW**. Details for the contact appear in the display.
4. If the entry contains more than one number, use ▲ or ▼ to highlight the desired number.
5. Press  to call the number.

Answering a Call

When you receive an incoming call, the Incoming screen appears in the display, press the  key to answer the call or **Ignore** () soft key to send the call to voicemail, or **Quiet** () soft key to silence the ringer.

Note: To change the answer options, see "Answer Options" on page 119.

Answering Call-Waiting Calls

- When you receive a call while on a call, the Incoming screen displays. You can press  and answer the new call or let the new call go to your voicemail.
- If you choose  and answer the incoming call, the original caller is placed on call waiting. To return to your original call when you finish with an incoming call, press the  Send key.

Recent Calls

When you place, miss, or receive a call, a record of the call is saved in Recent Calls, which is a listing of the different types of calls you can either receive or make. These types of calls are listed below.

- **Missed:** Displays any missed calls.
- **Received:** Displays any received calls that were answered.
- **Dialed:** Displays all outgoing calls made from your phone.
- **All:** Displays all missed, received, and outgoing calls made from your phone.

Viewing Call Information

Recent Calls retains information such as the duration, date and time, and whether the call was received, dialed, or missed.

1. At the standby screen, press the  key or press  **MENU** then press the right navigation key to highlight  **RECENT CALLS**. Press the up or down navigation key to highlight the call log that contains the number you want to view and press .
2. Press the down navigation key to highlight the desired number.
3. Once the desired number is highlighted, press  **OPEN**.
4. The following options appear in the display:
 - **“type” call:** Where “type” indicates if the call was missed, dialed, or received.
 - **Name:** If the caller is in your Contacts list, their name is listed here. This option only appears if the caller is in your Contacts list.
 - **Number:** Displays the telephone number as well as the appropriate icon to indicate mobile, work, or home number.
 - **Time:** The time of the call.
 - **Date:** The date of the call.
 - **Duration:** The duration of the calls made or receive.
5. Press the right soft key  **Options** to display the following options:
 - **Save:** Save the number to your Contacts list.
 - **Details:** Shows details of caller if they are in your Contacts list. Otherwise, this option is not displayed.

- **Erase:** Delete the call from Call History.
 - **Lock/Unlock:** locks or unlocks the entry to prevent accidental deletion.
 - **Erase All:** Delete the entire Call History list at one time.
 - **View Timers:** Select to view the call timers for your phone.
6. Press the down navigation key to highlight an option.
Press  to enter the highlighted option's sub-menu.

Call History Icons

When you view Recent Calls, an icon to the left of the number indicates the type of call.



Indicates a Missed call



Indicates a Dialed call



Indicates a Received call

Making Calls Using Call History

1. At the standby screen, press  then press up or down navigation key until the desired number is highlighted.
2. Press  to call the highlighted number. Or, you can press  **OPEN**, then press  to call the highlighted number.

Creating or Updating Contacts Using Call History

1. At the standby screen, press  then press up or down navigation key until the desired number is highlighted.
2. Press the right soft key  **Options**. **Save** is highlighted. Press .

3. Use the up or down navigation keys to highlight **Create New** or **Update Existing**. Press .
4. Use the up or down navigation keys to highlight one of the following options:
 - Mobile 1
 - Mobile 2
 - Home
 - Work
 - Fax
5. Press  to add a new contact, and then enter information.
6. Use the navigation keys to enter additional information for the entry and then press  **SAVE**.

Delete Call History Entries

1. At the standby screen, press  then press up or down navigation key until the desired number is highlighted.
2. Press the right soft key  **Options**. A pop-up menu appears in the display.
3. Press the down navigation key to highlight **Erase** and press . Select **Yes** or **No** at the **ERASE ENTRY?** pop-up screen.
4. Press .

Delete All Call History Entries

1. At the standby screen, press .
2. Press the right soft key  **Options**. A pop-up menu appears in the display.
3. Press the down navigation key to highlight **Erase All** and press . Select **Yes** or **No** at the **ERASE ALL ENTRIES?** pop-up screen.
4. Press .

Roaming

What is Roaming?

Your phone can roam on other digital networks. Roaming occurs when you travel outside a pre-designated coverage area. The roaming icon displays when roaming is active and extra charges may apply when making or receiving calls.

Note: Some features may be unavailable while roaming.

Roaming Options

The following roaming options are available:

- **Home Only** - Your phone is available for normal operation only in the designated coverage area.
- **Automatic-A:** The preferred roaming list is used to acquire service. If no preferred systems are found, any digital "A" system is acquired.
- **Automatic-B:** The preferred roaming list is used to acquire service. If no preferred systems are found, any digital "B" system is acquired.

Note: Contact your service provider for information regarding preferred systems.

To change your Roaming option, follow these steps:

1. Press  **MENU**. Use the right navigation key to highlight  **SETTINGS & TOOLS**.
2. Press  **Phone Settings**.
3. Press  **System Select**.
4. Use the up or down navigation keys to choose the setting you want, and press .

TTY

Your phone is fully TTY compatible. Connect the TTY equipment to the headset jack, which is located on the right side of the phone. Before you can use your phone with a TTY device, you'll need to enable TTY functions in the phone.

1. Press  **MENU**. Use the right navigation key to highlight  **SETTINGS & TOOLS**.
2. Press  **Call Settings**.
3. Press  **TTY Mode**. The TTY Mode screen displays.
4. A warning appears in the display stating **"ENABLING TTY WILL DISABLE HEADSET AUDIO. CONTINUE?"**

Use the up or down navigation key to highlight **Yes** and press  to proceed to TTY MODE screen.

Use the up or down navigation key to highlight **No** and press  to return to **Call Settings** menu.

5. Use the up or down navigation keys to select one of the following:
 - TTY Full
 - TTY + Talk (VCO)
 - TTY + Hear (HCO)
 - TTY Off
6. Press  to make your selection. The **TTY MODE SET** screen displays.

VoiceSignal™

VoiceSignal is advanced speech recognition software that can be used to activate a wide-variety of functions on your phone. VoiceSignal software automatically voice activates all contacts for voice dialing and searching, no pre-recording or training needed. Speak phone numbers naturally to dial, and use voice commands to launch applications and navigate phone menus.

VoiceSignal Settings

You can adjust the settings and preferences for VoiceSignal by opening Voice Commands menu. Using this menu, you can change the following Voice Command features:

- Tips for adapting Digit Dial
- Digit Dial Adaptation
- Reset Digit Dial Adaptation
- Call Digit Dialing
- Call Name Dialing
- Send Text Msg.

- Send Picture
- Name Lookup
- Opening Apps
- Checking Phone Status

To access the VoiceSignal Settings menu, follow these steps:

1. At the standby screen, press  **MENU**. Use the right navigation key to highlight  **SETTINGS & TOOLS**.
2. Press  **Tools**, then  **Voice Commands**, and  **Voice Settings**.
3. Use the navigation keys to select the setting you want to change. The following options are available:
 - **Choice Lists:** If VoiceSignal is not absolutely confident that it has correctly identified a name or number, it can display a choice list of up to three possibilities, and prompt you to confirm the correct one. You can control when choice lists appear by changing the Choice Lists setting to the following:
 - **Automatic:** VoiceSignal displays a choice list when it is not confident it has identified the correct choice from among multiple alternatives.
 - **Always On:** When there are multiple alternatives, VoiceSignal always displays a choice list.
 - **Always Off:** VoiceSignal never displays a choice list. Instead, the application picks the best from among the possible choices.
 - **Sensitivity:** In VoiceSignal, sensitivity controls the balance between rejecting too much, which means the phone frequently does not recognize names, numbers, or commands, and rejecting too little, which means it frequently recognizes something even if nothing was said.

When VoiceSignal rejects an utterance, it displays a message such as “Please repeat...” or “No match found.” If you frequently experience these messages, you might be able to get better recognition by adjusting the Sensitivity setting toward **Reject Less**. If you frequently experience false activations (VoiceSignal detects a wrong match), you might be able to get better performance by adjusting the Sensitivity setting toward **Reject More**.

- **Digit Dialing:** Use the Digit Dialing menu to adapt digit dialing to your voice.
 - **Adapt Digits:** Lets you adapt digits, which can improve voice recognition of phone numbers. Adaptation takes about 180 seconds.
 - **Reset Digits:** Erases any digit adaptation you have done and resets digit recognition to the factory default. If you have not adapted digits, this option is grayed out.
- **Sound:** You can customize the VoiceSignal user interface by turning playback on or off for prompts, names, and numbers. You can also change the speed and volume of name playback.
 - **Prompts:** Turns playback on or off for prompts such as “Say a command.”
 - **Digits:** Turns playback on or off for digits, for example, when confirming a phone number.
 - **Names:** Turns playback on or off for names.
 - **Name Settings:** Adjusts the speed and volume of name playback.
- **About:** Displays information about VoiceSignal including version number, build number, and device number.

You can also access the VoiceSignal Settings menu by following these steps:

1. In standby mode, press the  key.

2. Press the left soft key  **Settings**.
3. Use the navigation keys to select the setting you want to change.

Adapting VoiceSignal

Voice dialing works well for most people without special adaptation. However, people with strong accents or unique voice characteristics may receive better results after adapting the system to match their voices.

You should adapt Digit Dial only if the system is frequently unable to recognize your speech. After you adapt Digit Dial, your phone is customized to your voice, and your voice only. Others will not be able to use it unless they reset the phone to factory defaults.

Adaptation involves recording several digit sequences to adapt the system to the unique properties of your voice. The adaptation process takes about three minutes.

Tips for adapting Digit Dial

- Adapt digits in a quiet place.
- Make sure you wait for the beep before starting to speak.
- Speak clearly, and say each digit distinctly.
- If you make a mistake while recording a sequence of digits, or if there is an unexpected noise that spoils the recording, re-record that sequence.
- Only adapt digits if you regularly have problems with digit dialing. Once adapted, digit dialing will not work as well for other people using your phone.
- Adapt Digit Dial to your voice.

Digit Dial Adaptation

To access the Adapt Digits menu, follow these steps:

1. At the standby screen, press  **MENU**. Use the right navigation key to highlight  **SETTINGS & TOOLS**.
2. Press  **Tools**, then  **Voice Commands**.
3. Press  **Voice Settings**, then  **Digit Dialing**.
4. **Adapt Digits** is highlighted. Press .
5. A short description of the Adapt Digits displays.
6. Read the description until you are comfortable to proceed, then press .
7. Your phone displays the first digit sequence and “Please say” plays through the speaker followed by the four digits appearing in the display.

Wait for the beep and repeat the digits using your normal tone of voice.

8. After a moment, the phone plays back the recording and prompts “Did the recording sound ok?” If the recording was good, say “Yes.” If you need to re-record, say “No.”
If you say “No,” the phone prompts you to pronounce the digits again. Wait for the beep and then re-record.
Repeat this step until you’re satisfied with the recording.
9. After confirming that the recording sounds ok, repeat the recording process with the next set of digits. After ten sets of digits, the phone indicates that adaptation is complete.

Reset Digit Dial Adaptation

This option erases an adaptation and resets Digit Dial to its original state.

1. At the standby screen, press  **MENU**. Use the right navigation key to highlight  **SETTINGS & TOOLS**.
2. Press  **Tools**, then  **Voice Commands**.
3. Press  **Voice Settings**, then  **Digit Dialing**.
4. Highlight  **Reset Digits** and press . The Reset Digit Adaptation screen displays requesting confirmation of reset.

Note: If you have not performed the Adapt Digits function, the Reset Digits option will not be accessible.

5. Press  to proceed. Digit Adaptation Reset is completed.

VoiceSignal Commands

The following is a list of functions that you can perform using VoiceSignal speech recognition on your phone.

- **Call <Name> <Loc.>**: Dial by saying a Name in your Contacts List or a Name and a Location (home, work, mobile).
- **Call <Number>**: Dial by saying the number you want.
- **Send Text<Name>**: Send a text message to a number or to someone in your Contacts List.
- **Send Picture <Name>**: Send a PIX message to a number or to someone in your Contacts List.
- **Lookup <Name>**: Open the contact record for any name in your Contacts List.

- **Go to <Menu>:** Open any application installed on your device.
- **Check <Item>:** Provides details of your coverage, signal strength, and battery level.

Call Digit Dialing

Digit Dial allows you to dial any phone number by simply speaking the digits into the phone. No training is necessary, and Digit Dial is programmed to understand natural speech.

1. In standby mode, press the  key.
2. After a brief pause, a list of optional commands appears in the display and the audio prompt “Say a command” plays through the earpiece or speakerphone--if it is enabled.
3. Say “Call” at a distance of 3-12 inches from the phone in a natural voice.
4. “Say the name or number” plays through the earpiece.
5. To use Digit Dialing, say the area code and number that you want to dial into the microphone, clearly and naturally.
6. The number that you said is repeated through the earpiece and your phone dials the number.
7. If VoiceSignal is not sure of the number that you said, a list of possible matches appears in the display.
8. You’re asked to confirm the correct number as VoiceSignal displays the results. Say “Yes” or “No” to confirm or reject the number when prompted.

Call Name Dialing

To use Name Dial, you'll need to have entries stored in your Contacts list. See page 69 for information on creating a Contacts list.

1. In standby mode, press the  key.
2. After a brief pause, a list of optional commands appears in the display and the audio prompt "Say a command" plays through the earpiece.
3. Say "Call" at a distance of 3-12 inches from the phone in a natural voice.
4. "Say the name or number" plays through the earpiece or speakerphone--if it is enabled.
5. To use Name Dialing, say the name of the contact that you want to dial.
6. The name that you said is repeated through the earpiece and your phone dials the number.
7. If VoiceSignal is not sure of the number that you said, a list of possible matches appears in the display.
8. You're asked to confirm the correct number as VoiceSignal displays the results. Say "Yes" or "No" to confirm or reject the number when prompted.
9. The location is repeated through the earpiece and your phone dials the number.

Send Text MSG

1. In standby mode, press the  key.

2. A list of commands appears in the display and the audio prompt "Say a command" plays through the earpiece or speakerphone--if it is enabled.
3. Say "Send Text" at a distance of 3-12 inches from the microphone. "Say the name or number" plays through the earpiece or speakerphone.
4. Say the name exactly as it is displayed in your Contacts list, first name followed by last name.
5. The contact name appears in the To: field. See "Creating and Sending TXT Messages" on page 83 for more information.

Send Picture

Send Picture allows you to access PIX message, you can use entries stored in My PIX or you can take a picture of an image using the camera.

1. In standby mode, press the  key.
2. A list of commands appears in the display and the audio prompt "Say a command" plays through the earpiece or speakerphone--if it is enabled.
3. Say "Send Picture " at a distance of 3-12 inches from the microphone. "Say the name or number" plays through the earpiece or speakerphone.
4. Say the name exactly as it is displayed in your Contacts list, first name followed by last name.
5. The contact name appears in the To: field. See "Creating and Sending PIX/FLIX Messages" on page 85 for more information.

Name Lookup

To perform a name lookup, you'll need to have some entries in your Contacts list.

1. In standby mode, press the  key.
2. A list of commands appears in the display and the audio prompt "Say a command" plays through the earpiece or speakerphone--if it is enabled.
3. Say "Lookup" at a distance of 3-12 inches from the microphone. "Say the name or number" plays through the earpiece or speakerphone.
4. Say the name exactly as it is displayed in your Contacts list, first name followed by last name.
5. The contact name appears in the display with other information that you've entered for that contact.

Opening Apps

To open any application on your phone using VoiceSignal perform the following.

1. In standby mode, press the  key.
2. A list of commands appears in the display and the audio prompt "Say a command" plays through the earpiece or speakerphone--if it is enabled.
3. Say "Go To" at a distance of 3-12 inches from the microphone. A list of options displays and a prompt of "Please choose" plays through the earpiece or speakerphone.
4. The menu option spoken opens.

Checking Phone Status

1. In standby mode, press the  key.
2. A list of commands appears in the display and the audio prompt “Say a command” plays through the earpiece or speakerphone--if it is enabled.
3. Say “Check” at a distance of 3-12 inches from the microphone. “Please choose” plays through the earpiece or speakerphone.
4. The option spoken opens.

Section 4: Menu Navigation

Topics Covered

- Menu Navigation
 - Menu Outline
-

This section explains the menu navigation for your phone. It also includes an outline of all the available menus associated with your phone.

Menu Navigation

Access menus using the navigation keys, two soft keys  , or use a shortcut.

1. In standby mode press  **MENU**. The first of several menus appear in the display.
2. Use the navigation keys to browse phone menus.
3. Press  to enter the menu or sub-menu presently appearing in the display.

Return to the Previous Menu

Press  to return to the previous menu.

Navigate Using Shortcuts

You can also access menus and sub-menus using menu numbers. This method is often called a “shortcut.” To shortcut to a menu or sub-menu, press  **MENU**, then enter the menu and / or sub-menu number(s) for the feature in question. Use "Navigation Key Shortcuts" on page 53, for looking up the menu shortcut number.

1. In standby mode, press  **MENU**. The  **CONTACTS** menu is launched.
2. Press the number of the menu. Example, press  **Groups**,  **Business**.

Navigation Key Shortcuts

In standby mode, press a navigation key (as illustrated below) to launch its corresponding application.



The Shortcut menu is set to Calendar by default, but it can be customized to select other functions instead.

In standby mode, press **OK MENU**, use the right navigation key to highlight **SETTINGS & TOOLS**. Press **5 Phone Settings** **2 Shortcut Key**. The shortcut key list displays. Use the navigation key to change the setting and press **OK** to save your selection.

The In-Use Option

Access numerous menus and features even while in a call.

Note: If the call is disconnected while accessing the In-Use Option, the In-Use Option disappears from the display and the phone eventually returns to standby mode.

1. While in a call, press the right soft key **Options**. The following menu items appear in the display.
 - **Message:** Open the Messages menu.
 - **Contacts:** Open the contacts to view.

- **Recent Calls:** Display your recent incoming, missed and outgoing calls.
 - **Send DTMF:** Allows you to send your phone number as DTMF tones to the another person.
 - **Voice Privacy:** Prevent recipients of your calls from seeing your number on their display. Select from standard or enhanced options.
 - **Location:** Identifies your location to the network.
 - **Voice Memo:** Record a voice memo.
2. Use the navigation key to highlight a menu. Press  to open the highlighted menu or to activate the feature.

Menu Outline

The following list shows the menu structure and indicates the number assigned to each option.



GET IT NOW

- 1: Get Tunes & Tones
 - 1: Get V CAST Music
- 2: Get New Ringtones
 - 1: Get New App.
- 3: My Ringtones
 - 1: Get New Ringtones
 - 1: Get New App.
- 4: My Music
 - Get V CAST Music
 - Play All Songs
- 5: My Sounds
 - 1: Record New
- 6: Sync Music
- 7: Manage Music
- 2: Get PIX & FLIX
 - 1: Get V CAST Video

- 2: Get New PIX
 - 1: Get New App.
- 3: My PIX
- 4: My FLIX
- 5: PIX Place
- 6: Take PIX
- 7: Record FLIX
- 3: Get Fun & Games
 - 1: Get New App.
- 4: Get News & Info
- 5: Get Going
 - 1: Get New App.
- 6: Get Extras
 - 1: Get New App.



MESSAGING

- 1: New Msg
 - 1: TXT Msg
 - 2: PIX Msg
 - 3: FLIX Msg
 - 4: Sketch Msg
 - 5: Postcard
- 2: Inbox
- 3: Sent
- 4: Drafts
- 5: Voicemail
- 6: E-Mail
- 7: Mobile IM
- 8: Chat



CONTACTS

- 1: New Contact
- 2: Contact List
- 3: Groups
 - 1: No Group

- 2: Business
- 3: Colleague
- 4: Family
- 5: Friends
- 4: Speed Dials
- 5: My Name Card



RECENT CALLS

- 1: Missed
- 2: Received
- 3: Dialed
- 4: All
- 5: View Timers



SETTINGS & TOOLS

- 1: My Account
- 2: Tools
 - 1: Voice Commands
 - 1: Voice Dial
 - 2: Voice Settings
 - 3: Menu Readout
 - 2: Calculator
 - 1: Normal
 - 2: Tip
 - 3: Converter
 - 3: Calendar
 - 4: Alarm Clock
 - 5: World Clock
 - 6: Stop Watch
 - 7: Notepad
- 3: Sounds Settings
 - 1: Master Volume
 - 2: Call Sounds
 - 1: Call Ringtone
 - 1: My Ringtones

- 2: My Sounds
- 2: Call Vibrate
- 3: Alert Sounds
 - 1: TXT Message
 - 1: Tone
 - 1: My Ringtones
 - 2: My Sounds
 - 2: Vibrate
 - 3: Reminder
 - 2: PIX-FLIX Msg
 - 1: Tone
 - 1: My Ringtones
 - 2: My Sounds
 - 2: Vibrate
 - 3: Reminder
 - 3: Voicemail Msg
 - 1: Tone
 - 1: My Ringtones
 - 2: My Sounds
 - 2: Vibrate
 - 3: Reminder
 - 4: Device Connect
- 4: Keypad Volume
- 5: Earpiece Volume
- 6: Service Alerts
 - 1: ERI
 - 2: Minute Beep
 - 3: Call Connect
- 7: Power On/Off
 - 1: Power On
 - 2: Power Off
- 8: VibeTonz
- 4: Display Settings
 - 1: Banner

- 1: Personal
- 2: ERI Banner
- 2: Backlight
 - 1: Display
 - 1: Duration
 - 2: Brightness
 - 2: Keypad
- 3: Wallpaper
 - 1: My PIX
 - 2: My FLIX
- 4: Display Theme
- 5: Clock Format
- 6: Power On/Off
 - 1: Power On
 - 1: My PIX
 - 2: Pre-loaded Animation
 - 2: Power Off
 - 1: My PIX
 - 2: Pre-loaded Animation
- 7: Dialing Font
- 5: Phone Settings
 - 1: Standalone Mode
 - 2: Shortcut Key
 - 3: Language
 - 4: Location
 - 5: Security
 - 6: System Select
 - 7: NAM Selection
 - 8: PC Connection
 - 9: Quick Search
- 6: Call Settings
 - 1: Answer Options
 - 2: Auto Retry
 - 3: TTY Mode

- 4: One Touch Dial
- 5: Voice Privacy
- 6: Call Restrictions
 - 1: Outgoing
 - 2: Incoming
 - 3: Contacts
- 7: Data Settings
- 8: DTMF Tones
- 9: Ringer ID
- 0: Picture ID
- 7: Bluetooth
 - 1: Add New Device
- 8: Memory
 - 1: Save Options
 - 2: Phone Memory
 - 3: Card Memory
- 9: Phone Info
 - 1: My Number
 - 2: SW Version
 - 3: Icon Glossary

Section 5: Entering Text

Topics Covered

- Changing the Text Entry Mode
 - Using Word Mode
 - Entering Upper and Lower Case
 - Entering Symbols
 - Entering Numbers
-

This section outlines how to select the desired text input mode when entering characters into your phone. This section also describes how to use the T9 predictive text entry system to reduce the amount of key strokes associated with entering text.

Changing the Text Entry Mode

1. While composing a message in the Text area, press the right soft key  **Options** to display the following options:
 - **Add:** Allows you to add more information or multimedia items to your message.
 - **Graphics:** Lists preloaded and downloaded graphics to add to the message.
 - **Animations:** Lists preloaded and downloaded animations to add to the message.
 - **Sounds:** Lists preloaded and downloaded sounds to add to the message.
 - **Quick Text:** Choose from up to 12 pre-loaded messages. You can add 10 additional messages by pressing the right soft key  **New** and erase messages by pressing the left soft key  **Erase**.
 - **Name Card:** Select from My Name Card or Contacts to add to the message.
 - **Edit Text Format:** Change font size, text alignment, style, background and color.
 - **Save As Draft:** Save the message to your Draft folder.
 - **Priority Level:** Save the message with a High or Normal priority.
 - **Callback #:** Provides the option to send a callback number with the message.
 - **Validity Period:** Save the message for the assigned period of time.
 - **Deferred Delivery:** Save the message to be delivered at the assigned delivery date and time.
 - **Enh. Delivery Ack:** Displays a pop-up screen notifying the message sent has been received.

- **Add To Contacts:** Save the recipients number to your Contacts as a new entry or add to an existing entry.
2. While composing a message, press left soft key  **Abc** to display a pop-up menu with the following Text Entry Mode options:
 - Word
 - Abc
 - ABC
 - 123
 - Symbols

Using Word Mode

Word recognizes the most commonly used word for any sequence of key presses and inserts that word into your message. It's much faster than the traditional method of text entry (Abc) and requires only one key press per letter of the word that you're spelling.

1. In standby mode, press the left soft key  **Message**, then press  **New Msg**,  **TXT Msg** to compose a new text message.
2. Enter the phone number or email address of the recipient, then press the down navigation key to move to the Text field.
3. Press the left soft key  **Abc** to display a pop-up menu containing text entry mode options.
4. **Abc** is highlighted by default. Use the up/down navigation keys to highlight **Word**, then press .

Now, for practice, enter the word “Hello” into your message by pressing each of the following keys only once:



H



E



L



L



O

Word recognizes that the most frequently used word for the sequence of numbers entered. The word you just entered is “HELLO.” If more than one word shares the same sequence, Word provides the most common of the two. Press to display other words in the dictionary, if available.

Entering Upper and Lower Case

- Enter characters while in **ABC** mode by pressing the key that contains the desired characters for “G”.
- Press the key repeatedly to cycle through other available characters for that key.
- Pause briefly when the desired character appears in the display to accept the character and therefore insert it into the message.
- Press to enter a space.
- To cycle between uppercase, lower case, and initial caps for characters in **ABC** mode, briefly press .

Entering Symbols

Symbol mode enables you to enter symbols such as @ or % into a text message.

1. In standby mode, press the left soft key  **Message**, then press  **New Msg**,  **TXT Msg** to compose a new text message.
2. Enter the phone number or email address of the recipient, then press the down navigation key to enter text.
3. Press the left soft key  **Abc** to display a pop-up menu containing the text entry mode options.
4. **Abc** is highlighted by default. Use the up/down navigation keys to highlight **Symbols**, then press . The first of three screens containing symbols appears in the display.
5. Press  **Prev** or  **Next** to page through the other symbols, if necessary.
6. Enter the key that corresponds with the symbol that you wish to enter. For example, press  for an exclamation point (!) on the first page of symbols.
7. Repeat steps 3 through 6 to insert as many symbols into your message as desired.

Entering Numbers

Enter numbers into a text message while in number mode (**123**). See "Changing the Text Entry Mode" on page 62 for instructions on changing text entry modes.

1. In standby mode, press the left soft key  **Message**, then press  **New Msg**,  **TXT Msg** to compose a new text message.
2. Enter the phone number or email address of the recipient, then press the down navigation key to enter text.
3. Press the left soft key  **Abc** to display a pop-up menu containing the text entry mode options.
4. **Abc** is highlighted by default. Use the up/down navigation keys to highlight **123**, then press .
5. Enter the key that corresponds with the number that you wish to enter. For example, press  for the number **4**.
6. When you are finished adding numbers, press the left soft key  **123** to change to another Text Entry Mode or press  **SEND** to send your message.

Section 6: Understanding Your Contacts

Topics Covered

- Opening Contacts Menu
 - Adding a Contact
 - Adding Pauses
 - Contact Groups
 - Finding a Contact Entry
 - Editing an Existing Contact Entry
 - Deleting a Contact Entry
 - Storing Numbers After a Call
 - Speed Dialing
 - My Name Card
 - Finding My Phone Number
-

This section allows you to manage your daily contacts by storing their name and number in your Contacts menu. Contact entries can be sorted by name, entry, or group.

Opening Contacts Menu

The Contacts menu provides access to powerful features such as adding Groups, creating and sending V-cards, and viewing the phone number assigned to your phone by Verizon Wireless.

1. In standby mode, press  **MENU**. The  **CONTACTS** menu displays.
 - **New Contact:** Add a number, or e-mail address to your Contacts.
 - **Contact List:** Find a phone number by Name.
 - **Groups:** Add new or rename one of your five default groups.
 - **Speed Dials:** Set a speed dial for a contact.
 - **My Name Card:** Create a business card, which can then be sent to others as an attachment
2. Use the navigation key to highlight the  **CONTACTS** sub-menu of your choice, then press .

Contacts Icons

You can assign multiple entries to a contact. The icons in the following table represent all available entry types

- | | |
|---|--|
|  | Mobile 1 icon. Enter a mobile number for the entry in this field. |
|  | Home icon. Enter a home number for the entry in this field. |
|  | Work icon. Enter the work number for the entry in this field. |
|  | E-mail 1 icon. Enter an e-mail address for the entry in this field. |

-  **Group** icon. Select an available group to associate with the entry in this field.
-  **Ringtone** icon. Select a ringtone to associate with the entry in this field.
-  **Mobile 2** icon. Enter a secondary mobile number for the entry in this field.
-  **Fax** icon. Enter a fax number for the entry in this field.
-  **E-mail 2** icon. Enter a secondary e-mail address for the entry in this field.

Adding a Contact

When you add information to your Contacts, you can add it as a new entry or as an existing entry.

Method 1

1. In standby mode, press  **MENU**, the  **CONTACTS** menu opens.
2. Press  **New Contact** to enter the contact information.
3. Enter a name for the entry using the keypad.
4. Use the navigation key to highlight the appropriate type (**Mobile**, **Home**, **Work**, **E-mail**, etc.). Once highlighted, use the keypad to enter required information.
Use the navigation key to highlight other type fields, if desired. Enter information using the keypad.
5. To assign a **Speed Dial** location after entering the number, press the right soft key  **Options**. Highlight **Set Speed Dial** and press .

Highlight an unassigned location and press  **SET**. A confirmation message appears in the display, **Yes** is highlighted, press  to add the Contact to the speed dial location.

Note: Voicemail is assigned to Speed Dial location 1.

Note: You can assign a speed dial location to each number associated with the contact (**Home**, **Work**, **Mobile**, **Mobile 2**, and **Fax**.).

6. When you're finished entering information for the entry, press  **SAVE** to save the entry to your Contacts.

Method 2

You can add new numbers to the Contacts by simply entering the number while the phone is in standby mode, then following the necessary prompts to complete the process.

1. In standby mode, enter the number that you wish to save using the keypad, then press the left soft key  **Save**. You're prompted to select from **Create New** or **Update Existing**.
2. Press  to enter the number as a **Create New**, or press  to append the number to **Update Existing**.
3. If you selected **Create New**, the following types are available.
 -  **Mobile 1**
 -  **Mobile 2**
 -  **Home**
 -  **Work**

- **Fax**

4. If you selected **Update Existing**, proceed to step 8.
5. Use the up/down navigation keys to highlight the desired entry type (mobile, home, work, etc.) then press .
6. Enter a name for the entry using the keypad. Press the left soft key  **Abc** if you wish to select a different method of text entry, such as Word, Abc, ABC, 123, or Symbols.
7. To assign a **Speed Dial** location, use the up/down navigation key to highlight the number you would like to assign to a **Speed Dial** location and press the right soft key  **Options**. Highlight **Set Speed Dial** and press .

Highlight an unassigned location and press  **SET**. A confirmation message appears in the display, **Yes** is highlighted, press  to add Contact to the speed dial location.

Note: Voicemail is assigned to Speed Dial location 1.

Note: You can assign a speed dial location to each number associated with the contact (**Home**, **Work**, **Mobile**, **Mobile 2**, and **Fax**).

8. When you're finished entering information for the entry, press  **SAVE**. The entry is saved to your Contacts.

9. If you selected **Update Existing**, the Contact List opens in Search mode. Use the navigation key to browse through entries, or enter the name of the entry using the keypad. Once you've highlighted the entry you wish to append the number, press .
10. An UPDATE EXISTING pop-up screen with a selection list of entry types displays. Use the up or down navigation keys to highlight the desired type then press . The number is appended to the selected entry and saved to your Contacts.

Adding Pauses

Calls to automated systems often require a password or account number. Instead of manually entering numbers each time, store the numbers to your Contacts along with special characters called pauses.

- **Wait:** A hard pause stops the calling sequence until further input from you.
 - **2-sec pause:** A two-second pause stops the calling sequence for two seconds and then automatically sends the remaining digits.
1. In standby mode, enter the number.
 2. Press  **Options** use the navigation key to highlight **Wait** (A "W" appears in the display.) or **2-sec Pause** (A "P" appears in the display.) and press .
 3. When you're finished entering information for the entry, press  **SAVE**. The entry is saved to your Contacts.
 4. Continue with Step 2, Method 2 of **Adding a Contact**.

Note: Entering multiple two-second pauses extends the length of a pause. For example, two consecutive two-second pauses cause a total pause time of four seconds. Keep in mind pauses count as digits towards the 48-digit maximum.

Contact Groups

You can place Contact entries into categories, called “**Groups**.” Groups allow you to search your Contacts faster, quickly send messages to one or more group members, and more.

Note: By default, new entries to your Contacts are placed into the No Group unless another group is specified.

View Groups

1. In standby mode, press  **MENU**, then press  **Groups**. The following groups appear in the display.
 - **No Group**
 - **Business**
 - **Colleague**
 - **Family**
 - **Friends**
2. Use the navigation key to highlight the desired group, then press  to access the group and view its contents.

Move an Entry to Another Group

1. In standby mode, press the right soft key  **Contacts**. Use the navigation key to highlight the contact you wish to move.

2. Press the left soft key  **Edit**. Use the up/down navigation key to scroll to the Group option.
3. Press the left soft key  **Set**. Choose from the following groups:
 - **No Group**
 - **Business**
 - **Colleague**
 - **Family**
 - **Friends**
4. Use the navigation key to highlight the group containing the entry that you wish to move, then press .
5. Press  **SAVE**. The selection has been saved to the designated group.

Create a New Group

In addition to the five groups already in your phone, you can create additional groups (a maximum of 30). New groups can be named anything you like as long as their names are within the 32-character limit.

1. In standby mode, press  **MENU**, then press  **Groups**. Your existing groups appear in the display.
2. Press the left soft key  **New**. A **NEW GROUP** pop-up menu displays with the “Enter new name” highlighted.
3. Press  **SAVE** to save. The Groups list now displays the new group added.

Send a Text Message to Members of a Group

Use Send Message in the Group feature to send a message to as many as 10 members of a group at once.

Note: Text messaging availability varies when roaming off the Verizon Wireless Network.

1. In standby mode, press  **MENU**, then press  **Groups**. Your existing groups appear in the display.
2. Highlight the desired group name and press the right soft key  **Options**. Highlight **Send TXT Msg** and press .
3. Use the down navigation key to highlight the contacts in the group to which you want to send a message. Press  to place a checkmark next to each selection to send messages to.
4. Press the left soft key  **Done** after selecting up to 10 contacts.

Note: You can mark up to 10 members of a group for message distribution. If you try and mark an 11th member, you'll be notified that "**MAXIMUM RECIPIENTS IS 10**".

5. Press the down navigation key to place the cursor in the Text field.
6. Enter the content of your message using the keypad.
7. To send the text message, press  **SEND**.

Send a PIX/FLIX Msg to Members of a Group

Note: Only available within Verizon Wireless Enhanced Services Area.

1. In standby mode, press  **MENU**, then press  **Groups**. Your existing groups appear in the display.

2. Highlight the desired group name and press the right soft key  **Options**. Highlight **Send PIX/FLIX Msg** and press .
3. Use the down navigation key to highlight the contacts in the group to which you want to send a message. Press  to place a checkmark next to each selection to send messages to.
4. Press the left soft key  **Done** after selecting up to 10 contacts.
5. The CREATE PIX/FLIX MSG screen appears. Press the down navigation key to move the cursor into the following entry fields:
 - **Text**: Add text to the PIX/FLIX Msg.
 - **PIX/FLIX**: Add an image from the PIX or FLIX Gallery to the message.
 - **Sound**: Add sound to the PIX/FLIX Msg
 - **Subject**: Add a subject to the PIX/FLIX Msg.
 - **Name Card**: Attach a Name Card or an entry in your Contacts to the message.
6. Once you've finished adding the desired content to your PIX/FLIX Msg, press  **SEND** to send the PIX/FLIX Msg to the intended recipients.

Finding a Contacts Entry

From standby mode, you can quickly open the Contacts list. Contacts is a quick way of viewing entries you've stored in the Contacts list.

1. In standby mode, press the right soft key  **Contacts**. The Contact List displays.

2. In the Search field, enter the first and second letters of the name you wish to search until it is highlighted.

Editing an Existing Contact Entry

1. In standby mode, press  **MENU**, then press  **Contact List**.
2. Use the navigation key to highlight the contact list entry and press the left soft key  **Edit**.
3. Use the navigation key to highlight the name, number, e-mail address, or other field that you wish to edit.
4. Press  to backspace and delete numbers, text, or symbols.
5. Press and hold  to erase all numbers in the highlighted field.
6. Use the keypad to re-enter numbers, text, or symbols.
7. When you're finished editing the entry, press  **SAVE**. Your changes are saved.

Deleting a Contact Entry

1. In standby mode, press  **MENU**, then press  **Contact List**.
2. Use the navigation key to display the contact list entry and press  **VIEW**.
3. Press the left soft key  **Erase**.
4. A pop-up "ERASE ENTRY?" screen displays.
5. Highlight **Yes** or **No**, then press .

Storing Numbers After a Call

Once you've finished a call, you can store the number of the caller to your Contact List.

Note: If the call was incoming and Caller ID information was unavailable, then the store option is also unavailable.

1. After you press  to end your call, the call time, length of call and phone number appears in the display.
2. Press the right soft key  **Save**. You're prompted to confirm this as a **Create New**, or **Update Existing**.
3. Follow the on-screen prompts to designate other information.

Store a number in standby mode

Store a phone number by entering the number in standby mode, then press  **Save**. Follow the screen prompts to assign number types and other information.

Speed Dialing

Note: 1-Touch, 2-Touch, and 3-Touch dialing allows you to call numbers stored in your Contact List quicker.

Speed dialing allows you to press and hold a key (or keys) to dial the number associated with those key(s). There are three types of speed dialing; **1-touch**, **2-touch**, and **3-touch dialing**.

Note: Memory location 001 is reserved for voicemail.

1-touch dialing

Call phone numbers assigned to memory locations 002 - 009 by pressing and holding the any of the 2 - 9 keys. For example, to speed dial the number assigned to location 2, press and hold  until the name and number appear in the display and the number is dialed.

2-touch dialing

Call phone numbers assigned to keys 010 through 099 by briefly pressing the first key, then pressing and holding the second key. For example, to speed dial the number assigned to 013, briefly press , then press and hold  until the number dials.

3-touch dialing

Call phone numbers assigned to memory locations 100 through 999 by briefly pressing the first and second keys, then pressing and holding the third key. For example, to dial location number 113, briefly press , , then press and hold  until the number dials.

Assign a speed dial location

1. In standby mode, press  **MENU**, then press  **Speed Dials**. The Speed Dials screen displays with the first available number highlighted.
2. Use the navigation keys to highlight the number you wish to assign or enter the speed dial location using the keypad, press  **SET**.
3. The **SET SPEED DIAL** screen displays.
4. Use the navigation keys to highlight the entry you want, then press .

- At the pop-up screen, use the navigation key to highlight **Yes** or **No** and press .
- Continue to assign speed dial entries or press the  key to return to standby mode.

My Name Card

My Name Card allows you to create a virtual business card. Once completed, you can send the card to recipients as a V-card attachment.

- In standby mode, press  **MENU**, then press  **My Name Card**.
- My Name Card opens with the **Name** field highlighted.
- Enter information in each of the fields as desired. Use the navigation key to move between fields, then use the keypad to enter information.
- When finished, press  to save the Name Card.

Finding My Phone Number

My Number displays the ten-digit number assigned to your phone.

- In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**.
- Press  **Phone Info**.
- Press  **My Number**. The mobile device, phone number, and mobile identification number are displayed.

Section 7: Messaging

Topics Covered

- Types of Messages
 - Retrieving New Messages
 - Creating and Sending TXT Messages
 - Creating and Sending PIX/FLIX Messages
 - Receiving PIX/FLIX Messages
 - New Sketch Messages
 - Message Folders
 - Changing Message Settings
 - Voicemail
 - E-Mail
 - Mobile IM
 - Chat
-

This section allows you to send or receive different types of messages. It also includes the features and functionality associated with messaging.

Types of Messages

Your phone is capable of sending email, text, PIX & FLIX, sketch, post cards and voicemail messages. Send email, text, PIX & FLIX messages by simply entering the email address or the phone number of the recipient in the To: <.....> or Send To field when creating a new message.

Retrieving New Messages

While text messages from other phones are delivered directly to your phone, PIX / FLIX messages and emails will be stored in the Inbox of the message server and the server will alert you to new messages. Therefore you need to retrieve new messages to your phone and read them on the phone.

Retrieving a Text Message

When you receive a message in standby mode, the message ringer sounds, (unless turned off), and New Text Msg appears in the display along with the closed envelope icon . The date and time of the message also appear in the display.

1. Press  to **View now**, or press the down navigation key to highlight **View later** and press . The message is saved to your inbox where you can view it later.
2. With the message open, press the right soft key  **Options** to Forward, Reply w/copy, Save Graphic, Save Sound, Save Quick Text, Save Name Card, Lock, Add To Contacts or Message Info. Press the left soft key  **Erase** to erase the message.

3. With the message open, press  **REPLY** to return a message to the sender.

Note: When viewing a TXT message, you can view the previous TXT message by pressing the left navigation key and view the next TXT message by pressing the right navigation key.

Creating and Sending TXT Messages

You can send text messages to another mobile phone or to an email address.

1. In standby mode, press  **MENU**, then press the left navigation key to highlight  **MESSAGING**, press  **New Msg.** Or in standby mode, press the left soft key  **Message** then press  **New Msg.**
2. Press  **TXT Msg** to compose a new text message.
3. Enter the phone number or email address of the recipient.
4. Press the right soft key  **Options** to display a pop-up menu with the options listed.
 - **Entry Mode:** Choose from Word, Abc, ABC, 123, Symbols and Shortcuts modes of text entry.
 - **Save As Draft:** Save the message to your Draft folder.
 - **Priority Level:** Save the message with a High or Normal priority.
 - **Callback #:** Provides the ability to send a callback # with the message.
 - **Validity Period:** Save the message for the assigned period of time.
 - **Deferred Delivery:** Save the message to be delivered at the assigned delivery date and time.

- **Enh. Delivery Ack:** Displays a pop-up screen notifying the message sent has been received.
 - **Add To Contacts:** Save the recipients number to your Contacts as a new entry or add to an existing entry.
5. Press the left soft key  **Add** to select from the following options:
 - **Contacts:** Choose a number from your contacts list
 - **Groups:** Choose a group or a number from your group.
 - **Recent Calls:** Choose a number from the recent calls list.
 6. After selecting or entering your recipients in the **To** field, use the down navigation key, or  key to move to the message composer.
 7. In the text field, compose your message using the keypad. At any point while composing a message, press the right soft key  **Options** to display the following options:
 - **Add:** Add information from the following categories.
 - **Graphics:** Lists preloaded and downloaded graphics.
 - **Animations:** Lists preloaded and downloaded animations.
 - **Sounds:** Lists preloaded and downloaded sounds.
 - **Quick Text:** Choose from up to 12 pre-loaded messages. You can add 10 additional messages by pressing the right soft key  **New** and erase messages by pressing the left soft key  **Erase**.
 - **Name Card:** Attach My Name Card information or information from one of your Contacts.
 - **Edit Text Format:** Allows you to edit the text size, alignment, style, color, and background color.
 - **Save As Draft:** Save the message to your Draft folder.

- **Priority Level:** Save the message with a High or Normal priority.
 - **Callback #:** Provides the ability to send a callback # with the message.
 - **Validity Period:** Save the message for the assigned period of time.
 - **Deferred Delivery:** Save the message to be delivered at the assigned delivery date and time.
 - **Enh. Delivery Ack:** Turn message delivery acknowledgement Off or On.
 - **Add To Contacts:** Save the recipients number to your Contacts as a new entry or add to an existing entry.
8. Use the navigation key to highlight an option. Press  to perform the function for the option, or to enter its sub-menu.
 9. To send the message, press  **SEND**.

Creating and Sending PIX/FLIX Messages

Note: Only available within Verizon Wireless Enhanced Services Area.

You can add sounds and attach a Name Card or Contact entry to your PIX/FLIX Msg. This is also known as Multimedia Messaging (MMS).

1. In standby mode, press  **MENU**, then press the left navigation key to highlight  **MESSAGING**, press  **New Msg**. Or in standby mode, press the left soft key  **Message** then press  **New Msg**.
2. Press  **PIX Msg** or  **FLIX Msg** to compose a new message.

3. Enter the phone number or e-mail address of the recipient (or recipients) using the keypad.
4. Press the right soft key  **Options** to display a pop-up menu that provides the following options:
 - **Entry Mode:** Choose from Word, Abc, ABC, 123, Symbols and Shortcuts modes of text entry.
 - **Preview:** Shows the message before it is sent.
 - **Save As Draft:** Save the message to your Draft folder.
 - **Priority Level:** Save the message with a High or Normal priority.
 - **Validity Period:** Save the message for the assigned period of time.
 - **Deferred Delivery:** Save the message to be delivered at the assigned delivery date and time.
 - **Add To Contacts:** Save the recipients number to your Contacts as a new entry or add to an existing entry.
5. Press the left soft key  **Add** to select from the following options:
 - **Contacts:** Choose a number from your contacts list
 - **Groups:** Choose a group or a number from your group.
 - **Recent Calls:** Choose a number from the recent calls list.
 - **To PIX Place:** Send the message to the PIX Place.
6. Press  once you've finished entering the phone number(s) or email address(es).
7. In the Text field, compose your message.
8. Press the down navigation key to highlight the **PIX/FLIX** field. Press the left soft key  **My PIX/My FLIX** to add a PIX/FLIX, and follow the prompts. Press  to attach the highlighted object.

9. Press the up/down navigation key to highlight the **Sound** field. Press the left soft key  **Sounds** to select a sound. Press the up/down navigation key to highlight the desired sound and press .
10. Press the down navigation key to highlight the **Subject** field. Press the left soft key  **Abc** to change entry mode. Press the right soft key  **Options** to **Add Quick Text**. Press the up/down navigation key to highlight the desired Quick Text phrase, and press .
11. Press the down navigation key to add Name Card. Press the left soft key  **Add** to select **My Name Card** or an entry from your **Contacts** list. Follow the prompts and press  to insert.
12. Once all fields are complete, press  to send the message to the intended recipient(s).

Receiving PIX/FLIX Messages

When you receive a new PIX / FLIX Msg, **NEW PIX/FLIX MSG** appears in the display along with the options **View Now**, **View Later** or **Reject**.

Note: For the option **Reject** to appear in the display when you receive a PIX/FLIX Msg, **Auto Receive** mode must be set to **Off** in the Message Settings menu.

1. When you receive a new PIX/FLIX Msg, press  **View Now**. Downloading... appears in the display.
2. After downloading, the image (and text if any) contained in the PIX/FLIX Msg appear in the display.

3. Use the navigation keys to scroll through the message or view the entire picture if necessary.

Note: When viewing a PIX/FLIX message, you can view the previous PIX/FLIX message by pressing the left navigation key and view the next PIX/FLIX message by pressing the right navigation key.

Receive Messages While in a Call

When you receive a message while in a call, the **NEW PIX/FLIX MESSAGE** dialog box appears in the display. Press  to clear. You can view the message without disconnecting your call by pressing  **Options** and then selecting **Message**.

Reject a PIX/FLIX Msg

Note: For the option **Reject** to appear in the display when you receive a PIX/FLIX Msg, **Auto Receive** mode must be set to **Off** in the Message Settings menu.

This feature is currently unavailable outside of the United States.

1. When you get notification to view a new PIX/FLIX Msg that you don't want to receive, press the down navigation key to highlight **Reject**.
2. Press  to reject.

View a PIX/FLIX Msg Later

1. When you receive a new PIX/FLIX Msg that you would like to view later, highlight **View Later** and press .
2. To view the message, press the left soft key  **Message**,  **Inbox**.

3. Use the navigation key to highlight the unopened message, then press  **OPEN**. The **INBOX** screen appears first with information about the message. Press  **DOWNLOAD** to view PIX/FLIX message.

New Sketch Messages

You can convert a picture to a black and white sketch drawing that can be sent with a message. For information on taking a picture see "Take PIX" on page 146. For information on sending the message, see "Creating and Sending PIX/FLIX Messages" on page 85.

Message Folders

Your phone provides default message folders for your Text and PIX/FLIX messages.

Note: To quickly view all messages in the Inbox, Sent, or Drafts folders, open one message and then press the right navigation key to view the next message or press the left navigation key to view the previous message.

Inbox

Received messages of all types are stored in the Inbox folder.

1. In standby mode, press the left soft key  **Message** then press  **Inbox**. Or in standby mode, press  **MENU** and use the left navigation key to highlight  **MESSAGING** then press  **Inbox**.
2. Use the navigation key to highlight the message that you wish to view.

3. Press  **OPEN** to view contents of the highlighted message.
4. While viewing a message press the right soft key  **Options** to display the options listed.
 - **Play Again:** Replays a PIX/FLIX message.
 - **Forward:** Forward the message to another recipient.
 - **Erase:** Deletes the message.
 - **Save PIX/FLIX:** Saves the picture sent in a PIX/FLIX message to **My PIX** or **My FLIX**.
 - **Save Sound:** Saves the sound received with the message.
 - **Save Quick Text:** Saves the text received in the message to the Quick Text list.
 - **Save Name Card:** Saves the name card received in the message.
 - **Lock:** Locks the message to prevent deletion.
 - **Add To Contacts:** Save the number of the sender to your Contacts as a new entry or add to an existing entry.
 - **Message Info:** Provides the following information: From (also provides the date and time the message was sent), Callback Number, Priority, Msg Type, Size and if a PIX, Sound or Name Card were included in the message.
5. Press the  **REPLY** key to return a message to the sender.
6. From the Inbox menu, press the left soft key  **Erase** to delete the message from the Inbox. Highlight **Yes** to delete, or **No** to return to the Inbox menu.

Note: When Auto Erase is turned on, the oldest read TXT message is replaced by an incoming TXT message when 50 TXT messages are stored in the Inbox, and the oldest read PIX/FLIX message is replaced by an incoming PIX/FLIX message when 50 PIX/FLIX messages are stored in the Inbox. See "Changing Message Settings" on page 95 for information on how to set Auto Erase and Auto Receive.

Sent

Your phone stores messages in the Sent folder, regardless of whether the message was successfully transmitted. Verify if and when a message or e-mail was successfully transmitted by enabling the **Enh. Delivery Ack** feature in Message Settings.

Note: Enh. Delivery Ack can't be set for PIX/FLIX message.

Review Messages in the Sent Folder

1. In standby mode, press the left soft key  **Message** then press  **Sent**. Or in standby mode, press  **MENU** and use the left navigation key to highlight  **MESSAGING** then press  **Sent**.
2. Use the navigation key to highlight the message that you wish to review, then press  **OPEN**.
3. While viewing the message, press the right soft key  **Options** to display the options listed.
 - **Play Again:** Replays a PIX/FLIX message.
 - **Forward:** Forwards the message to another recipient.
 - **Erase:** Deletes the message.
 - **Lock/Unlock:** Locks the message to prevent deletion.
 - **Save Quick Text:** Saves the text sent in the message to the Quick Text list.

- **Add To Contacts:** Adds the sender's information to your contact list.
- **Message Info:** Provides the following information: Send To Number (also provides the date and time the message was sent), Priority, Msg Type, Size, Attachments (if a Graphic, Sound or Name Card were included in the message), Status, and Error Code.

4. Use the navigation key to highlight the desired option.
5. Press  to perform the function for the highlighted option.
6. Press the left soft key  **Play** to play the FLIX message.
7. Press  **RESEND** to send the message to the recipient again.
8. From the **Sent** menu, press the left soft key  **Erase** to delete the message from the Sent folder. Highlight **Yes** to delete, or **No** to return to the Sent menu.

Drafts

Draft messages are those that have been composed but never sent. You can return to the Drafts folder at any time to view, edit, or send a draft message.

Create a Draft Text Message

1. In standby mode, press  **MENU**, then press the left navigation key to highlight  **MESSAGING**, press  **New Msg**. Or in standby mode, press the left soft key  **Message** then press  **New Msg**.
2. Select the type of message you want to create.

3. Enter the phone number of the recipient, then press the down navigation key.
4. Compose your message using the keypad, then press the right soft key  **Options**. A pop-up menu appears in the display.
5. Scroll down with the navigation key until **Save As Draft** is highlighted, then press . A confirmation message appears in the display and your message is saved to the Drafts folder.

View and Edit Draft Messages

1. In standby mode, press the left soft key  **Message** then press  **Drafts**. Or in standby mode, press  **MENU** and use the left navigation key to highlight  **MESSAGING** then press  **Drafts**.
2. Use the navigation key to highlight the message that you wish to view, then press  **EDIT**. The message opens in the Text field with the message text displayed.
3. Press the **CLR** key  to backspace and delete any current characters in the display, if desired. Press and hold  to erase all characters in the field.
4. Press the right soft key  **Options**. A pop-up menu appears in the display with the options listed.
 - **Add:** Add information from the following categories.
 - **Graphics:** Lists all graphics pre-loaded and downloaded.
 - **Animations:** Lists all animations pre-loaded and downloaded.
 - **Sounds:** Lists all sounds pre-loaded and downloaded.

- **Quick Text:** Choose from up to 12 pre-loaded messages. You can add 10 additional messages by pressing the right soft key  **New** and erase messages by pressing the left soft key  **Erase**.
 - **Name Card:** Allows you to add your name card or the name card of one of your contacts.
 - **Edit Text Format:** Allows you to edit the text size, alignment, style, color, and background color.
 - **Save As Draft:** Save the message to your Draft folder.
 - **Priority Level:** Save the message with a High or Normal priority.
 - **Callback #:** Provides the ability to send a callback # when sending a message.
 - **Validity Period:** Save the message for the assigned period of time.
 - **Deferred Delivery:** Save the message to be delivered at the assigned delivery date and time.
 - **Enh. Delivery Ack:** Displays a pop-up screen notifying the message sent has been received.
 - **Add to Contacts:** Save the recipients number to your Contacts as a new entry or add to an existing entry.
5. Use the navigation key to highlight the desired option. Press  to perform the function for the highlighted option.
 6. Once you've returned to the message composer, press  to send the message, if desired.

Erase Options

You can erase unlocked messages in your Inbox, Drafts folder, or Sent folder. Locked messages are not erased.

To erase messages:

1. In standby mode, press  **MENU**, then press the left navigation key to highlight  **MESSAGING**, then press the right soft key  **Options**.
2. The following options are available:
 - **Erase Inbox:** Erases unlocked messages in your Inbox.
 - **Erase Drafts:** Erases unlocked messages in your Drafts folder.
 - **Erase Sent:** Erases unlocked messages in your Sent folder.
 - **Erase All:** Erases unlocked messages in all message folders (Inbox, Drafts and Sent).

Changing Message Settings

This menu allows you to define settings for messages sent or received on your phone. To access your message settings, use the following steps:

1. In standby mode, press  **MENU**, then press the left navigation key to highlight  **MESSAGING**, then press the left soft key  **Settings**. Or press the left soft key  **Message** and press the left soft key  **Settings**.
2. Select the message type you would like to change and press . Choose from the following options:
 - **All Msg:** Allows you make a broadcast change to all message settings.
 - **Auto Save:** Saves all messages sent. Use the navigation keys to select On, Off, or Prompt.
 - **Auto Erase:** Erases the oldest message of the same type (TXT or PIX/FLIX) when the maximum number of received messages of that type is exceeded in the Inbox. For example, the oldest read TXT message is replaced by an incoming TXT message when 50 TXT messages are stored in the Inbox, and the oldest read PIX/FLIX message is replaced by an incoming PIX/FLIX

message when 50 PIX/FLIX messages are stored in the Inbox. Choose from On or Off.

- **Quick Text:** Displays the Quick Text pre-defined entries for Text Msg and PIX/FLIX Msg. Press the right soft key  New to add to the Quick Text list. Enter your new text and press  . The new Quick Text item shows in the first position of the list.
- **Voice Mail #:** Enter the speed dial entry set for your voicemail.
- **Entry Mode:** Sets the default entry mode for messaging. Choose from Word, Abc, ABC, or 123.
- **Callback #:** Displays the callback number in the text message. Choose from On or Off.
- **Signature:** Adds the signature text to each message sent. Choose from None or Custom.
- **TXT Msg:** Allows you to customize Text Msg. settings.
 - **Auto View:** Automatically displays the text message when received. Choose from On or Off.
 - **Signature:** Adds the signature text to each message sent. Choose from None or Custom.
 - **Text Auto Scroll:** When enabled, advances body text automatically one line at a time.
- **PIX-FLIX Msg:** Allows you to customize PIX-FLIX Msg. settings.
 - **Auto Receive:** Automatically receives messages into your Inbox. Choose from On or Off.
 - **Signature:** Adds the signature text to each message sent. Choose from None or Custom.

Voicemail

New voicemail alerts are sent via an SMS text message. These messages indicate how many new and urgent voicemails are in your box. Open the text message to view the number of new and urgent voice messages in your voicemailbox. If a caller leaves a callback number, this number will also be sent via an SMS text message.

Receive Voicemail Messages

When you receive a new voicemail message you'll hear a sound and an SMS text message appears in the display.

1. Press the up/down navigation keys to select **Listen Now** or **Listen Later**.
2. Press .

View Voicemail Messages in the Inbox Folder

1. In standby mode, press  **MENU**, then press the left navigation key to highlight  **MESSAGING**, press  **Voicemail**. Or press the left soft key  **Message** and press  **Voicemail**.
2. Press  **OPEN** to dial voicemail and retrieve your message(s).

E-Mail

This menu allows you to send and receive E-Mail using Mobile Web. To use your E-Mail, follow these steps:

1. In standby mode, press  **MENU**, then press the left navigation key to highlight  **MESSAGING**, then press  **E-Mail**. Or press the left soft key  **Message** and press  **E-Mail**.
2. Using the up and down navigation keys, select one of the following E-Mail providers and press .

- MSN Hotmail
 - AOL Mail
 - Yahoo! Mail
 - Find More
3. Use the on-screen application specific functions and options to use the E-Mail applications.

Mobile IM

The Instant Messaging function allows you to send and receive instant messages using one of the following communities:

- AOL® Instant Messenger™
- MSN® Messenger Service
- Yahoo!® Messenger

Note: You must first create the Instant Message account before accessing it on your phone.

Using Mobile IM

1. In standby mode, press  **MENU**, then press the left navigation key to highlight  **MESSAGING**, then press  **Mobile IM**. Or press the left soft key  **Message** and press  **Mobile IM**.
2. Highlight **Mobile IM** and press .
3. Select your instant message community using the left and right navigation keys and press .
4. Use the on-screen application specific functions and options to use the instant message applications.

Chat

You have the ability to join wireless chat rooms from your phone. Send messages including text and icons to many chat room participants or launch one-on-one (private) chat rooms.

To access a chat room from the browser:

1. In standby mode, press  **MENU**, then press the left navigation key to highlight  **MESSAGING**, then press  **Chat**. Or press the left soft key  **Message** and press  **Chat**.
2. Mobile Web is launched. Using the up and down navigation keys, select one of the following chat rooms and press .
 - UPOC CHAT
 - LAVALIFE
 - FRIENDZ
 - LIFESTYLE
 - POWER CHAT
 - FIND MORE
3. Use the on-screen application specific functions and options to use the Chat applications.

Section 8: Changing Your Settings

Topics Covered

- My Account
 - Tools
 - Sounds Settings
 - Display Settings
 - Phone Settings
 - Call Settings
 - Bluetooth
 - Memory
 - Phone Info
-

This section explains the sound and phone settings for your phone. It includes display settings, security settings, Bluetooth settings, call settings, and other settings associated with your phone.

My Account

The My Account menu connects to the VZW Mobile Web. You can setup Favorites or choose from the available applications.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **My Account**. The menus are listed in the display.
2. Use the navigation keys to make your selection and press . Follow the on-screen instructions.

Tools

The Tools menu provides the ability to access the following menus:

- **Voice Commands:** For more information see, "VoiceSignal™" on page 39.
- **Calculator:** For more information see, "Calculator" on page 156.
- **Calendar:** For more information see, "Calendar" on page 158.
- **Alarm Clock:** For more information see, "Alarm Clock" on page 161.
- **World Clock:** For more information see, "World Clock" on page 163.
- **Stop Watch:** For more information see, "Stop Watch" on page 164.
- **Notepad:** For more information see, "Notepad" on page 165.

Sounds Settings

The Sounds menu provides the ability to access the following menus:

Master Volume

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Sounds Settings**. The **Sounds Settings** menus are listed in the display.
2. Press  **Master Volume**.
3. Use the **Up** and **Down** navigation keys to adjust the volume. Press the **Play** soft key to hear the volume.
4. Press  **SET** to save.

Call Sounds

Ringer Settings

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Sounds Settings**. The **Sounds Settings** menus are listed in the display.
2. Press  **Call Sounds**. Press  **Call Ringtone**. Available options are:
 - **My Ringtones**: You can get new ringtones from the web, or choose from pre-loaded ringtones and VibeTonz. VibeTonz display with the VibeTonz icon .
 - **My Sounds**: You can choose from the list of pre-loaded ringtones.
3. Press  **Call Vibrate** to set the Call Sounds to vibrate.

4. Press  to save the setting. The phone returns to the Call Sounds menu.

Alert Sounds

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Sounds Settings**. The **Sounds Settings** menus are listed in the display.
2. Press  **Alert Sounds**. For the following options, you can set the tone for the message alerts. You can also set vibration on and set a reminder.
 - **TXT Message**: allow you to set a notification for TXT message.
 - **PIX-FLIX Msg**: allow you to set a notification for PIX-FLIX message.
 - **Voicemail Msg**: allow you to set a notification for Voicemail Msg.
 - **Device Connect**: allow you to set a notification when you connect to a device.

Keypad Volume

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Sounds Settings**. The **Sounds Settings** menus are listed in the display.
2. Press  **Keypad Volume**.
3. Use the **Up** and **Down** navigation keys to adjust the keypad volume.
4. Press  **SET** to save.

Earpiece Volume

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Sounds Settings**. The **Sounds Settings** menus are listed in the display.
2. Press  **Earpiece Volume**.
3. Use the **Up** and **Down** navigation keys to adjust the keypad volume.
4. Press  **SET** to save.

Service Alerts

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Sounds Settings**. The **Sounds Settings** menus are listed in the display.
2. Press  **Service Alerts**. For the following options, you can turn the Service Alert **On** or **Off**.
 - **ERI**: Sounds an alert when you go into and out of your coverage areas.
 - **Minute Beep**: While on a call your phone beeps after every minute of usage.
 - **Call Connect**: Sounds an alert when a call is connected and when a call has ended.

Power On/Off

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Sounds Settings**. The **Sounds Settings** menus are listed in the display.

2. Press  **Power On/Off**. You can set the sounds for Power On and Power Off to either **On** or **Off**.

VibeTonz®

VibeTonz® provides a wide range of touch sensations that let you personalize your phone. Ringtones with VibeTonz® effects synchronized to the music are more fun and identifiable. Mobile games with VibeTonz® effects include a type of touch feedback similar to console games.

Note: The SCH-a930 comes with pre-loaded VibeTonz® ringtones. You may experience some resonance when closing the flip of the SCH-a930 as a result of this feature.

Note: VibeTonz-enhanced ringtones display the VibeTonz icon . By default VibeTonz is off.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Sounds Settings**. The **Sounds Settings** menus are listed in the display.
2. Press  **VibeTonz**. Set the touch sensation to **On**.

Display Settings

The **Display** menu affects the menu style, standby mode animation, backlight settings, and more.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Display Settings**. The **Display Settings** menus are listed in the display.

- **Banner:** Create your own personalized greeting that appears in the display when your phone is in standby mode or choose the ERI Banner which displays the network in which you have subscribed.
 - **Backlight:** Choose settings for the LCD and/or Keypad.
 - **Wallpaper:** Choose PIX (Pre-loaded or personal) or FLIX to use as the background display for your Main LCD.
 - **Display Theme:** Choose from 6 preset colors used for menu display.
 - **Clock Format:** Choose digital or analog format for time display.
 - **Power On/Off:** Choose the media that appears in the display when you turn the phone on and off.
 - **Dialing Font:** Choose a dialing font style.
2. Use the navigation key to highlight the display menu that you wish to edit, then press .
 3. Use the navigation key to select from the menu options that appear in the display, then press . Your settings are saved.

Banner

Banner allows you to create your own personalized greeting that appears in the display while your phone is in standby mode. Or you can display the network to which you are subscribed.

To create a personal banner:

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Display Settings**. The **Display Settings** menus are listed in the display. Press  **Banner**.

2. Press  **Personal** to create a customized **banner** for your handset.

Note: Press and hold  to erase an existing banner, if necessary.

3. Enter a word or short phrase (18 characters or less) to appear in your phone's display when the phone is in standby mode.
4. Press  to save the new banner.

To create an ERI banner:

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Display Settings**. The **Display Settings** menus are listed in the display. Press  **Banner**.
2. Press  to set the **ERI Banner** for your handset.
3. Select On or Off and press  to save the new setting.

Backlight

Set the **backlight** for the display or keypad to remain on for a specified period of time or to remain on as long as the flip is open.

Note: Prolonged backlight use drains your battery faster.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Display Settings**. The **Display Settings** menus are listed in the display. Press  **Backlight**. The menus listed appear in the display.
 - **Display:** The following options are for the Main LCD.

- **Duration:** Can be set to 7 seconds, 15 seconds, 30 seconds, Always On, or Always Off.
 - **Brightness:** Use the Navigation keys to adjust the brightness.
 - **Keypad:** The following options are for the keypad.
 - **7 Seconds:** The keypad is on for 7 seconds.
 - **15 Seconds:** The keypad is on for 15 seconds.
 - **30 Seconds:** The keypad is on for 30 seconds.
 - **Always On:** The keypad is always on.
 - **Always Off:** The keypad is always off.
2. Use the navigation key to highlight a menu.
 3. Press  to enter the highlighted option's menu and change settings as desired.

Wallpaper

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Display Settings**. The **Display Settings** menus are listed in the display. Press  **Wallpaper**. **My PIX**, and **My FLIX** appear in the display.
2. Use the navigation key to highlight **My PIX**, or **My FLIX**, then press .
3. Use the navigation key to highlight your selection, the press  to select the wallpaper that will appear in the main LCD display while your phone is in standby mode.

Display Theme

Choose from 6 preset colors used for menu display.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**.

Press  **Display Settings**. The **Display Settings** menus are listed in the display. Press  **Display Theme**.

2. Use the navigation keys to select the Display Theme you wish, then press .

Clock Format

This menu allows you to have time displayed in digital or analog format.

- Main Clock: Set to Digital, Analog, or Off
1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Display Settings**. The **Display Settings** menus are listed in the display. Press  **Clock Format**. The **Clock Format** menus are listed in the display.
 2. The following options appear in the display. Highlight one of the following options and press  to save.
 - **Digital**: Time appears in digital format, for example, 12:54pm.
 - **Analog**: Time appears in clock format. Digital format is still present in the display.
 - **Off**: No time is displayed.

Power On/Off

Animation allows you to choose the multi-media or pictures that appear in your phone's display when you turn it on or turn it off.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**.

Press **4** **Display Settings**. The **Display Settings** menus are listed in the display. Press **6** **Power On/Off**.

2. Use the navigation key to highlight **Power On** or **Power Off**, then press **OK**.
3. Use the navigation keys to select from **My PIX** or **Pre-loaded Animation**.
4. If you selected **My PIX**, choose from the available files. Press **OK** to save settings.
5. If you selected **Pre-loaded Animation**, choose from the available files, and press **OK** to save settings.

Dialing Font

1. In standby mode, press **OK** **MENU**, use the right navigation key to highlight **SETTINGS & TOOLS**. Press **4** **Display Settings**. The **Display Settings** menus are listed in the display. Press **7** **Dialing Font**.
2. Choose from Normal, Quill Pen, Sticky, and Color Dial.
3. Use the navigation keys to select a dialing font preferences, then press **OK**.

Phone Settings

The Phone Settings menu provides the ability to access the following menus:

Standalone Mode

With **Standalone Mode** on, all RF functions for your phone are disabled, and you cannot use your phone to place or receive calls.

1. In standby mode, press **OK** **MENU**, use the right

navigation key to highlight  **SETTINGS & TOOLS**.

Press  **Phone Settings**. The **Phone Settings** menus are listed in the display.

2. Press  **Standalone Mode**. Use the Up or Down navigation key to select **On** or **Off** and press .

Shortcut Key

Shortcut Key allows you to select from up to 21 applications that appear in the display when you press the down navigation key in standby mode.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Phone Settings**. The **Phone Settings** menus are listed in the display. Press  **Shortcut Key**.
2. Use the navigation key to select the menu item shortcut of your choice, then press .

Language

Change the display language from English to Spanish or vice versa using the **Language** menu.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Phone Settings**. The **Phone Settings** menus are listed in the display. Press  **Language**.
2. Use the navigation key to select the language of your choice, then press .

Location

Note: This feature is only available on the Verizon Wireless network.

The **Location** (GPS) setting identifies your location to the network. You can fully enable this setting or set GPS to work only in the case that you dial 911 from your phone.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Phone Settings**. The **Phone Settings** menus are listed in the display.
2. Press  **Location**. The Location screen displays.
 - **Location On**: GPS location setting is on wherever the feature is available.
 - **E911 Only**: GPS location setting is on whenever you dial 911 only.
3. Use the navigation key to highlight an option.
4. Press  to select the highlighted setting.

Security

The **Security** menu allows you to lock your phone, set restrictions, and other security options.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Phone Settings**.
2. Use the navigation key to highlight **Security**, press .
3. Enter the lock code (factory settings are the last four digits of your telephone number). The following options display:
 - **Common Code**: Common code On, uses a common password for both device and location lock code. Common code Off, uses separate passwords for both device and location.
 - **Lock Mode**: Allows you to lock the **Device** or **Location**.

- **Edit Code:** Allows you to change the **Lock Code** for the **Device** or **Location**.
- **Reset Phone:** All settings (except Contacts) are reset to factory default settings.

Lock Phone

Lock Phone restricts the use of your phone with the exception of outgoing calls to 911. Lock Phone allows you to answer calls, but to place calls (except to emergency numbers) you have to unlock the phone.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Phone Settings**. The **Phone Settings** menus are listed in the display. Press  **Security**. You're prompted to enter the lock code. The default lock code is the last four digits of your telephone number.
2. Enter the **Lock Code**. Several security menus appear in the display.
3. Press  **Lock Mode**. Use the navigation key to highlight **Device**. Press . The following options display:
 - **Lock:** Your phone returns to standby mode. The the Lock Code is required immediately to access any functions.
 - **Unlock:** If locked, unlocks the device or phone, depending on your selection.
 - **On Power Up:** The Lock Code is required whenever you power up the phone.
4. Press  to perform the function for the highlighted option.

Lock Location

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Phone Settings**. The **Phone Settings** menus are listed in the display. Press  **Security**. You're prompted to enter the lock code. The default lock code is the last four digits of your telephone number.
2. Enter the **Lock Code**. Several security menus appear in the display.
3. Press  **Lock Mode**. Use the navigation key to highlight **Location**. Press . The following options display:
 - **Lock**: Your phone returns to standby mode. The the Lock Code is required immediately to access any functions.
 - **Unlock**: If locked, unlocks the device or phone, depending on your selection.
4. Press  to perform the function for the highlighted option.

Edit Lock Code

The default lock code is the last four digits of your phone number. **Edit Code** allows you to change this code to a lock code of your preference.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Phone Settings**. The **Phone Settings** menus are listed in the display.
2. Press  **Security**. You're prompted to enter the lock code. The default lock code is the last four digits of your telephone number.

3. Press  **Edit Code**. Two options are available **Device** and **Location**. Use the navigation keys to highlight your choice and press .
4. At the “ENTER NEW LOCK CODE” or “ENTER NEW LOCATION LOCK CODE” prompt, enter the new lock code. You’re prompted to confirm the new lock code.
5. “DEVICE CODE SET” or “LOCATION LOCK CODE SET” message appears in the display confirming that your lock code has been changed.

Note: Your phone does not allow you to view the lock code for obvious security reasons. If you change the lock code, be sure to write down or memorize the new code.

Resetting Your Phone

Reset Phone returns all setup options to their factory default.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Phone Settings**. The **Phone Settings** menus are listed in the display.
2. Press  **Security**, and enter the lock code. Press  **Reset Phone**. A prompt appears in the display asking if you wish to restore default settings (except for the Contacts).
3. Press **Yes** to restore default settings or press **No** to return to the Security list.

Emergency

Note: Emergency number 911 is hard-coded into your phone. You can dial this number any time, even when the phone is locked or restricted. If you call 911 an audible tone is heard and an emergency prompt appears in the display for the duration of the call.

Important: DO NOT depend on this phone as a primary method of calling 911 or for any other essential or emergency communications.

Remember to always turn your phone on and check for adequate signal strength before placing a call.

Call Emergency Numbers in Lock Mode

In Lock Mode, you can dial 911 to place an emergency call.

Note: If you dial 911, your phone dials the emergency number immediately (no prompt).

System Select

The **System Select** menu allows you to set your roaming options. For information on roaming options, see "Roaming Options" on page 37.

NAM Selection

Your phone provides the option of selecting between two NAMs (Number Assignment Modules) or phone numbers. Select either NAM1 or NAM2.

PC Connection

PC Connection allows you to select how you want your a930 to connect to your PC. Choose either USB, or Bluetooth

and press . Select No Connection to disable PC Connection.

Quick Search

Quick Search is an easy way to locate contacts in your Address Book and Menu items.

Searching for a Contact

1. In standby mode, press the first few numeric keys that correspond to the letters of the contacts name.

For example, to search for “Sally” you would enter



2. Press the **Up** navigation key. The contact name is highlighted.
3. Press the  key to call the contact.

Searching for a Menu Item

1. In standby mode, press the first few numeric keys that correspond to the letters of the Menu item name.

For example, to search for “Inbox” you would enter



2. Press the **Down** navigation key. The menu item is highlighted.

3. Press the  key to access the content of the menu item.

Call Settings

The **Call Settings** menu allows you to select the method for answering incoming calls, setting redial options, setting data rates for data calls, voice privacy, and more.

Answer Options

The Answer Options menu allows you to select the method for answering incoming calls.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Call Settings**. The **Call Settings** menus are listed in the display.
2. Press  **Answer Options**. The following options appear in the display:
 - **Flip Open**: Calls are answered when the flip is opened.
 - **Any Key**: Calls are answered when any key is pressed.
 - **Send Only**: Calls are answered when the  key is pressed.
 - **Auto Answer**: Calls are answered automatically with a 1, 3 or 5 second delay.
3. Use the navigation key to highlight the method you wish to use for answering calls, then press .

Auto Retry

Auto Retry automatically redials busy numbers after a preset period of time.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Call Settings**. The **Call Settings** menus are listed in the display.
2. Press  **Auto Retry**. The following options appear in the display:
 - **Off**
 - **Every 10 Seconds**
 - **Every 30 Seconds**
 - **Every 60 Seconds**
3. Highlight an option and press , or press  to return to the Call Settings menu without making a selection.

TTY Mode

Before you can use your phone with a TTY device, you'll need to enable TTY functions in the phone. See "TTY" on page 38 for more information.

One Touch Dial

You can use this option to enable or disable the speed dialing feature.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Call Settings**. The **Call Settings** menus are listed in the display.

2. Press  **One Touch Dial**. Select **On** or **Off**. Press  to save.

See "Speed Dialing" on page 78 for more information.

Voice Privacy

Note: This feature is only available on the Verizon Wireless network.

Voice Privacy (at the Enhanced setting) allows you to prevent those you call from seeing your number in their display when receiving your call. Voice privacy options are Standard and Enhanced.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Call Settings**. The **Call Settings** menus are listed in the display.
2. Press  **Voice Privacy**. The menus listed appear in the display. **Standard** and **Enhanced** appear in the display.
3. Use the navigation key to highlight the **Voice Privacy** option of your choice, then press . Your settings are saved.

Call Restrictions

Call Restriction allows you to restrict outgoing and incoming calls. You can also restrict access to your Contacts list.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Call Settings**. The **Call Settings** menus are listed in the display.

2. Press  **Call Restrictions**.
3. Use the navigation key to select **Outgoing, Incoming, or Contacts**, then press .
4. Use the navigation key to highlight **On** or **Off**, then press . Your settings are saved.

Data Settings

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Call Settings**. The **Call Settings** menus are listed in the display.
2. Press  **Data Settings**. The following options appear in the display. Highlight one of the following options and press .
 - **Data Off**: Phone operates in normal voice call mode.
 - **Data For Next Call**: Data call is enabled for next call only. Phone will reset to Data Off mode after call.
 - **Data Until Powered Off**: Phone will remain in Data Mode until phone is powered off.

DTMF Tones

Use this menu to set DTMF settings to **Normal**, or **Long**.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Call Settings**. The **Call Settings** menus are listed in the display.
2. Press  **DTMF Tones**. The following options appear in the display. Highlight one of the following options and press .
 - **Normal**: Select for a normal tone.

- **Long:** Select for an extended tone.

Ringer ID

The **Ringer ID** menu allows you to set the Ringer ID option to **On** so that you can associate different ringtones with different numbers. See "Get Tunes & Tones" on page 131 for more information.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Call Settings**. The **Call Settings** menus are listed in the display.
2. Press  **Ringer ID**. Highlight **On** or **Off** and press .

Picture ID

The **Picture ID** menu allows you to set the Picture ID option to **On** so that you can associate a picture with a Contact. See "Get PIX & FLIX" on page 142 for more information

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Call Settings**. The **Call Settings** menus are listed in the display.
2. Press  **Picture ID**. Highlight **On** or **Off** and press .

Bluetooth

About Bluetooth

Bluetooth is a short-range wireless communications technology capable of exchanging information over a distance of about 30 feet without requiring a physical connection.

Unlike infrared, you don't need to line up the devices to beam information with Bluetooth. If the devices are within a range of one another, you can exchange information between them, even if they are located in different rooms.

Note: When connected to your Bluetooth headset, press the headset send key to use Voice Signals Voice Dial feature.

Bluetooth Service Profiles

Actually, the Bluetooth specification is a protocol that describes how the short-range wireless technology works, whereas individual profiles describe the services supported by individual devices. Profiles reduce the chance that different devices will not work together.

Your phone supports the following profile service:

- HSP: Mono-headset profile
- Bluetooth handsfree kit support *
- HFP: Hands-free profile
- SPP: Serial Port profile
- DUN: Dial Up Networking

* For vehicle / accessory compatibility, go to www.verizonwireless.com/bluetooth-chart. Phone does not support Bluetooth OBEX profiles.

The following Bluetooth options are available:

On/Off

When the Bluetooth radio is turned on, you can use the Bluetooth features available. When the Bluetooth radio is turned off, you cannot send or receive information via Bluetooth. To save battery life or in situations where radio

use is prohibited, such as airline traveling, you can turn off the Bluetooth wireless technology.

1. In standby mode, press  **MENU** key and use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Bluetooth**. The **Bluetooth** menus are listed in the display.
2. Press  to turn Bluetooth On or Off.

Note: If activated, the  Bluetooth icon displays.

Search

This option searches for a recognized Bluetooth wireless technology device.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Bluetooth**. The **Bluetooth** menus are listed in the display.
2. **Add New Device** is highlighted, press  twice.

Note: If you have NOT already activated Bluetooth on the phone, the message “TURN BLUETOOTH ON?” displays. Highlight **Yes** to activate or **No** to exit and press .

3. A list of found Bluetooth devices will be displayed. Use the **Up** and **Down** navigation keys to highlight a Bluetooth device. Press  to pair the devices.
4. Enter the passkey (0000 for most devices) and press  to pair with the device you selected.
5. Select **Yes** to pair the devices. Once connected the Bluetooth Connected icon  appears in the display.

Bluetooth Settings

The Bluetooth wireless technology settings menu provides the ability to view and change the device name, show the visibility, and set the security for the device.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Bluetooth**. The **Bluetooth** menus are listed in the display.
2. Press  **Settings**. The Bluetooth menu displays with the following options:
 - **My Phone Name**: allows you enter a customized name.
 - **Discovery Mode**: allows other users to see your accessibility. Select **On** for other devices to see your device, or **Off** for no visibility.

Note: After selecting On, users have one minute to see your accessibility. After which Discovery Mode will automatically default back to off.

- **My Phone Info**: shows the handset information.

Memory

The Manage Memory menu allows you to set your **Save Options** to **Phone Memory** or **Card Memory**. You can also set the memory usage for pictures, videos, music, sounds, and ringtones on your phone and microSD™ / TransFlash™ card.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Memory**. The **Memory** menus are listed in the display. The following options are available:

- **Save Options:** You can set your PIX, FLIX, and Sounds to be saved to either phone memory or card memory.
- **Phone Memory:** Allows you to see memory usage of everything stored on your phone.
- **Card Memory:** Allows you to see memory usage of everything stored on your microSD™/TransFlash™ card.

Phone Info

The **Phone Info** menu allows you to view the software and hardware information, your assigned number, and an icon glossary for your phone.

1. In standby mode, press  **MENU**, use the right navigation key to highlight  **SETTINGS & TOOLS**. Press  **Phone Info**. The **Phone Info** menus are listed in the display.
2. **My Number** is highlighted. Press  to display the Mobile Device and Identification numbers.
3. Press  **SW Version** to view the software, PRL, ERI, Browser, Get it Now, and Hardware versions available on your phone.
4. Press  **Icon Glossary** to view the list of icons with a brief description.
5. Press  to return.

Section 9: Multimedia

Topics Covered

- Get It Now
 - Get Tunes & Tones
 - Get PIX & FLIX
 - Get Fun & Games
 - Get News & Info
 - Get Going
 - Get Extras
-

This section describes how you receive tunes, tones, images, games, news and information. You can also take and send pictures and video from your phone.

Get It Now

The Get It Now menu provides sub-menus to GetTunes & Tones, Get PIX & FLIX, Get Fun & Games, Get News & Info, Get Going and Get Extras. You can also view memory info to see how much space you've used (and have left) for stored media. Use the following steps for each **GET IT NOW** sub-menu.

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press the right soft key  **Info**.

Note: you can directly access the **GET IT NOW** menu by pressing the right navigation key while in standby mode.

2. Press  **App. Memory** to display the memory available. Press the  key to return.
3. Press  **Content Memory** to view the memory used for the following items. Press the  key to return.
 - My Ringtones
 - My Music
 - My Sounds
 - My PIX
 - My FLIX
 - Applications
4. Press  **View Log** to see the file transfer activity. Press the  key to return.

5. Press  **Help** to display a list of frequently asked questions. Use the navigation key to highlight an item and press  to display help text. Press the  key to return.

Get Tunes & Tones

This menu allows you to get new tunes and tones, record new sounds, and set tunes and tones as your ringtone. It also allows you to access your music files.

Get V CAST Music

You can use the Get V CAST Music option to download music from the V CAST Music catalog directly to phone memory or to a removable memory card. Before downloading music to your microSD™ / TransFlash™ memory card, be sure to format it as described below.

Formatting microSD™ / TransFlash™ Card using your PC

For best playback of songs stored to the microSD™ / TransFlash™ memory card, you should reformat your memory card with PC format FAT32.

Note: Any contents currently stored on the microSD™ / TransFlash™ memory card will be lost after this procedure is performed.

1. Insert the microSD™ / TransFlash™ memory card into an SD card adapter.
2. Insert the SD card adapter into the SD card reader slot.
3. Plug the SD card reader into a USB port on your PC.
4. On your PC, go to your **My Computer** directory and highlight the drive that represents the SD card reader.

5. Right click and select the **Format** option.
6. Under the **File System** option, select **FAT32** and click the **Start** button.
7. Your microSD™/TransFlash™ memory card will be reformatted.
8. Remove the microSD™/TransFlash™ card from the SD card reader and insert it back into your phone. The **My Music** directory will automatically be created on the microSD™/TransFlash™ memory card the first time you insert it into the phone.

Formatting microSD™/TransFlash™ Card using your a930

1. In standby mode, press the  **Menu**, use the right navigation key to highlight  **Settings & Tools**.
2. Press  **Memory**.
3. Press  **Card Memory**.
4. Press the right soft key  **Options**.
5. The **Format Card** option is highlighted. Press .
6. Highlight **Yes** and press  to format microSD™/TransFlash™ card.

Downloading Music from the V CAST Music Catalog

1. In standby mode, press the  **Menu**, use the left navigation key to highlight  **Get It Now**. The **Get Tunes & Tones** menu is highlighted, press .
2. Press  **Get V CAST Music** to open the V CAST Music catalog.
3. Browse or search the catalog to preview the songs you want.

4. Highlight the music (song or album) that you want to purchase. Press  **BUY** to purchase.
5. The **CONFIRM PURCHASE** screen will display the price and items you selected to purchase. Press  **BUY** to accept the terms.
6. You'll receive confirmation that your purchase was successful and your music is available for download. Press  to continue.
7. Highlight **Phone Memory** or **Memory Card** for storage location (**Memory Card** is recommended). Press  to begin downloading. Wait for the phone to acquire the content license. Press  when download is complete.
8. Press  **Play** to play the downloaded song immediately.
 Or, You can press the left soft key  **Library** to go to your Music Library of downloaded songs and albums. See "Manage Music" on page 139 for more information.
9. To return to standby mode, press the  key.

Get New Ringtones

You can use this option to download new ringtones from the Internet.

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. The **Get Tunes & Tones** menu is highlighted, press .
2. Highlight  **Get New Ringtones** and press .
3. Highlight  **Get New App.** and press .

4. You are connected to the web server and presented with available provider ringtone applications.
5. To return to standby mode, press the  key.

My Ringtones

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. The **Get Tunes & Tones** menu is highlighted, press .
2. Highlight  **My Ringtones** and press .
3. Select  **Get New Ringtones** to access the web to download new ringtones. Or if you have already downloaded ringtones, highlight your selection and press .
4. To return to standby mode, press the  key.

VibeTonz®

See “VibeTonz®” on page 106 for more information.

Note: VibeTonz display the  VibeTonz icon.

My Music

The Music Player can be used to play music files that you have downloaded from the V CAST Music catalog or that you have transferred from your PC using Sync Music.

You can play your music with the flip open or closed.

Playing Music with the Flip Closed

The external keys which you will use are labeled below.



1. In standby mode, with your flip closed, press and hold the **Play/Pause** (▶ ||) key. If you have already downloaded music to your phone or memory card, **Play Music? Y:▶ || N:▶▶|** appears in the display.

Note: To create a playlist, see “Creating a Playlist” on page 140 for more information.

2. Press the **Play/Pause** (▶ ||) key to play the songs or press the **Fast Forward** (▶▶|) key to elect not to play music.
3. You can use the **Fast Forward** (▶▶|) and **Rewind** (|◀◀) keys to skip to another song track. Press and hold the **Fast Forward** (▶▶|) and **Rewind** (|◀◀) keys to forward or rewind the current song.

Playing Music with the Flip Open

1. In standby mode, press **OK** **MENU**, use the left navigation key to highlight **GET IT NOW**. The **Get**

Tunes & Tones menu is highlighted, press .

2. Highlight  **My Music** and press .
3. The Music Player opens with a list of music files that have been downloaded or transferred to internal phone memory or to the microSD™/TransFlash™ memory card. The **Get V CAST Music** option is also shown. See “Get V CAST Music” on page 131 for more information.
4. Scroll down to a song and press the right soft key  **Options**, to select from the following options:
 - **Move**: Moves the images from the microSD™/TransFlash™ card to the phone and from the phone to the microSD™/TransFlash™ card. Displays when microSD™/TransFlash™ card is inserted.
 - **Lock**: Allows you to lock the song so that it will not be deleted. This option may not be available for all songs.
 - **Erase**: Erases the selected file.
 - **Erase All**: Erases all files.
 - **Song Info**: Displays Title, Artist, Album, Genre, Copyright, Length, Size, Bit Rate and Date.
5. Press the up/down navigation keys to highlight the song you want to listen to and press  **PLAY** to play the song. Or, press the left soft key  **Playlist** to see a list of your playlists.
6. During song playback, press the right soft key  **Options** to switch to one of the following functions:
 - **Play All**: Selects all songs for playback.
 - **Shuffle**: Re-sorts the current playlist order.
 - **Get V CAST Music**: Connects you to the V CAST Music catalog to download more songs.

7. During song playback, press the right navigation key to advance to the next song track in the current playlist, or press the left navigation key to skip to the previous song track.

My Sounds

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. The **Get Tunes & Tones** menu is highlighted, press .
2. Highlight  **My Sounds** and press .
3. **Record New** is highlighted. Press  to launch the **RECORD NEW** screen.
4. Press  **REC** to begin recording. Press  **STOP** to stop. Press the left soft key  **Pause** to pause and resume the recording appropriately.
5. Press  to save sound.

Sync Music

This option allows you to transfer music files from your PC. In order to use this option, you must load Windows Media™ Player 10 on your PC. Windows Media™ Player 10 is only compatible with Windows XP® operating systems.

For setup of Windows Media™ Player 10, refer to the following resources:

- To download the Windows Media™ Player 10:
<http://www.microsoft.com/windows/windowsmedia/mp10/default.aspx>

- Tips on getting started:
<http://www.microsoft.com/windows/windowsmedia/mp10/usingplayer.aspx>
- Common questions:
<http://www.microsoft.com/windows/windowsmedia/mp10/troubleshooting.aspx>
- Troubleshooting error messages:
<http://www.microsoft.com/windows/windowsmedia/mp10/errors.aspx>

Note: The file name is limited to 36.3 characters (thirty-six to left of ".", three to right of ".").

Only songs with English or Spanish filenames can be successfully transferred to the phone for play back.

Note: Before transferring files, be sure to format your microSD™/TransFlash™ memory card with PC format FAT32. See "Formatting microSD™/TransFlash™ Card using your PC" on page 131 for more information.

1. Plug in the USB cable to your phone and connect it to a USB port on your PC.
2. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. The **Get Tunes & Tones** menu is highlighted, press .
3. Highlight  **Sync Music** and press .
4. Your phone should display the message, **Connected**.
5. Open Windows Media Player 10 on your PC and select the **SYNC** option.

6. The left-hand side of the Windows Media Player will display the files on your PC. Check the songs you want to download.
7. On the right-hand side of the Windows Media Player, select whether you want to download the music to **Removable storage card** or **Phone internal memory**.
8. Press the **Start Sync** button on the upper left-hand side of the Windows Media Player.
9. A **Synchronization Complete** message will appear on the phone when downloading is complete.
10. Disconnect the USB cable.
11. To return to standby mode, press the  key.

Manage Music

This option allows you to view your music sorted by genre, artist, album title, or song title. You can also create playlists.

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. The **Get Tunes & Tones** menu is highlighted, press .
2. Highlight  **Manage Music** and press .
3. Your Music Library will appear. The following categories are available:
 - **Genres**: This option organizes your songs by music type (genre). For example, Folk, Rock, Country, Classical, Soul, Unknown and so on. Each folder will contain all songs within that genre.
 - **Artists**: This option organizes your songs by artist.

- **Albums:** This option organizes your songs by album title. Even if you only have one song from an album, a folder for the album will display.
 - **Songs:** This option organizes your songs by song title. To add a song to a playlist, press the right soft key  **Options** and select **Add to playlist** to place the song into one of your playlists.
 - **Playlists:** Any playlists that you have created are displayed in this option. Press the right soft key  **Create** to create a new playlist. With a playlist highlighted, press the right soft key  **Options** to play, edit, rename, or erase the playlist, or to create a new playlist.
 - **Inbox:** This repository is where alert notifications are received when new music from a selected artist is available for download.
 - **Play All:** This option will play all of your songs in list order.
 - **Shuffle:** This option will re-sort a playlist order.
4. You can press the left soft key  **Catalog** to go to the **Get V CAST Music** catalog.

Creating a Playlist

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. The **Get Tunes & Tones** menu is highlighted, press .
2. Highlight  **Manage Music** and press .
3. Highlight  **Playlists** and press .
4. If playlist(s) already exist on the phone, press the right soft key  **Options**. Highlight  **Create playlist** and press .

Or, if no playlists exist, press the right soft key  **Create**.

5. Enter a title for the playlist in the text box and press .
6. Press the  key to return to the Music Library menu. You can select songs to add to the playlist by browsing through Genres, Artists, Albums, or Songs in the Manage Music library.
7. Highlight a song, press the right soft key  **Options** and select  **Add to Playlist**. Highlight the appropriate playlist and press  **ADD**.
8. To return to standby mode, press the  key.

Editing a Playlist

1. In standby mode, press  **MENU** and use the left navigation key to highlight  **GET IT NOW**. The **Get Tunes & Tones** menu is highlighted, press .
2. Highlight  **Manage Music** and press .
3. Highlight  **Playlists** and press .
4. Highlight the playlist you would like to edit and press the right soft key  **Options**. Highlight  **Edit playlist** and press .
5. To remove a song from the playlist, highlight the song and press the right soft key  **Remove**.
6. To change the order of the songs in your playlist, highlight a song and press  **Move**. Then use the Up or Down navigation keys to move the song up or down in the playlist order. When you are finished, press  **Save**.
7. To return to standby mode, press the  key.

Get PIX & FLIX

This menu allows you to get new PIX and FLIX from the internet or take new PIX or FLIX using your phone's camera. You can also view the saved pictures.

Get V CAST Video

V CAST, the next generation wireless technology that unveils a whole new multimedia experience at your fingertips, provides access to vibrant, full-color content from some of the biggest names in entertainment. V CAST is your link to video on demand, which allows you to view or download video clips that contain breaking news, sports highlights, weather and more.

For additional information regarding V CAST Video and its use, see www.verizonwireless.com.

Note: To access and download videos, you must have the  icon displayed.

Browsing, Selecting and Playing Video Clips

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Highlight **Get PIX & FLIX** and press .
2. The **Get V CAST Video** option is highlighted. Press .
3. Use the left or right navigation keys to highlight the **V CAST Video** category you want.
4. After choosing the category you want press . Choose a sub category, if applicable, by using the navigation keys or by entering the short-cut key number and press .

5. Use the navigation key to highlight a video. You may press the right soft key  **Options** to read the description of the video clip.
6. To view the highlighted video, press  **VIEW**.
7. Highlight **Yes** to accept charges, if applicable, and then press . After connection and buffering occurs, the video clip begins.

Downloading a Video Clip

1. Launch **V CAST Video** and select a video you want to save. For information about launching your video player and choosing a video clip, review steps 1-5 of the previous section, "Browsing, Selecting and Playing Video Clips" above.
2. To download and save the highlighted video, press  **SAVE**. The video clip will be saved to **My FLIX**.
3. Highlight **Yes** to accept charges, if applicable, and then press . The video download begins.
4. Once the download is completed, "**Download Complete. Play video now?**" appears in the display.
5. Select **Yes** and press  to view the video, or select **No** to return to the **V CAST Video** menu.

Note: Not all video content available can be downloaded to your phone; however, all content is available for viewing.

Deleting Video Clips

1. Launch **V CAST Video**. For information about launching your video player, review "Get New PIX" on page 145.

2. Press the right soft key  **Options**. **My Clips** is highlighted.
3. Press . The clips you have downloaded are listed.
4. Use the navigation key to highlight the video you want to erase and press the right soft key  **Options**. **Erase** is highlighted.
5. Press . Highlight **Yes** when the confirmation screen displays, then press .

Using the Video Gallery

The video clips you save are stored in **My FLIX**. You can access video clips without launching the **V CAST Video** application and delete your saved video clips directly.

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press **Get PIX & FLIX**.
2. Press  **My FLIX**.
3. Use the navigation key to highlight **V CAST Video**, then press .
4. Use the navigation key to highlight the video you want to delete and press the right soft key  **Options**.
5. Use the navigation key to highlight **Erase** and then press .
6. Highlight **Yes** to confirm that you want to erase the saved clip, then press .

Configure Alerts for New Video Clips

1. Launch **V CAST Video**.
2. Use the right and left navigation keys to select the **V CAST Video** categories you want to configure an alert.
3. Choose a sub category if applicable, then press the right soft key  **Options**.
4. Highlight **Alerts** and press .
5. Highlight **Configure alerts** and press .
6. Select the alert content you want, and press .
7. After reading terms, highlight **Save** to accept and press , or highlight **Cancel** to decline and press .

Note: Fees apply for text messages/alerts both sent and received.

Get New PIX

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press  **Get PIX & FLIX**.
2. To get new PIX press  **Get New PIX**. Press  **Get New App**. You are connected to the internet. Follow the on-screen prompts.

Take PIX

This menu launches the camera.

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press  **Get PIX & FLIX**.
2. Press  **Take PIX**. The camera is now active.
3. Press the right soft key  **Options**, to choose the specific camera settings. Use the right/left navigation keys to advance to each setting category, and the up/down navigation keys to make selections within each category. The following categories are available:
 - **Flash**: Off, Always On, Auto, On This Shot
 - **Self Timer**: Off, 2 Sec., 5 Sec., 10 Sec.
 - **Multi-Shot**: Series Shot, Divided Shot, Auto/Manual
 - **Quality**: Fine, Normal, Economy
 - **Resolution**: (1280X960), (640X480), (320X240), (160X120) and Picture ID
 - **White Balance**: Auto, Sunny, Cloudy, Tungsten, Fluorescent, and Manual
 - **Color Effects**: Normal, Black & White, Sepia, Antique, Negative, Green, Aqua, Cool, Warm, Sketch.
 - **Metering**: Average, Center, Spot
 - **Settings**: Memory (store PIX to phone or microSD™/TransFlash™ card), Auto Save, Icon Display, Shutter Sound, Reset Setting
 - **Camcorder**: Switches from Camera to Camcorder
4. Press and hold  **TAKE** to capture a picture. Press the right soft key  **Erase** to delete it or press the left soft key  **Save**. The picture is now saved to the Gallery.

5. To exit the camera, press the  key.

PIX Gallery

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press  **Get PIX & FLIX**.
2. Press  **Take PIX**. The camera is now active.

Note: When the phone memory is full camera mode cannot be activated.

3. Press the left soft key  **My PIX** to review the picture(s).
4. Press the right soft key  **Options** to view your pictures in a **Slide Show**, or to **Lock** the pictures from deletion. Highlight **Slide Show** and press . Press  **PAUSE** or the left soft key  **Done** to return.
5. From the **My PIX**, press  **VIEW** to view the highlighted picture. Press the right soft key  **Options** to select from the following options:
 - **Send:** Launches the Create PIX/FLIX Msg screen.
 - **To PIX Place:** Transfers the file to the online gallery.
 - **Get New:** Launches the internet to get online pictures.
 - **Set As:** Set the picture as the Main Wallpaper, Picture ID, or Power On/Off image.
 - **Create Postcard:** Adds text to a picture selected from the PIX Gallery.
 - **Slide Show:** Allows you to view of a series of pictures.
 - **Rename:** Allows you to rename the picture.

- **Move:** Moves the images from the microSD™/TransFlash™ card to the phone and from the phone to the microSD™/TransFlash™h card.
 - **Lock:** Locks the picture to prevent deletion.
 - **Erase:** Erases the selected picture from the gallery.
 - **Erase All:** Erases all pictures from the gallery except the locked images.
 - **PIX Info:** Provides the date, time, resolution, size and rights to the selected picture.
6. Use the navigation key to make your selection and press



Take FLIX

This menu launches the camcorder.

1. In standby mode, press **MENU**, use the left navigation key to highlight **GET IT NOW**. Press **Get PIX & FLIX**.
2. Press **Record FLIX**. The camcorder is now active. Press the right soft key **Options** to select from the following options:
 - **Recording Mode:** Limit for MMS (to record up to a 15 second clip to attach to a PIX/FLIX message), Normal (to record video with length up to 10 minutes at a time).
 - **Flash:** Off, Always On, Auto.
 - **Self Timer:** Off, 2 Sec., 5 Sec., 10 Sec.
 - **Quality:** Economy, Normal, or Fine. Quality is always set to Economy.
 - **White Balance:** Auto, Sunny, Cloudy, Tungsten, Fluorescent, Manual.

- **Color Effects:** Normal, Black & White, Sepia, Antique, Negative, Green, Aqua, Cool, Warm.
 - **Settings:** Memory (store FLIX to phone or microSD™/TransFlash™ card), Auto Save, Icon Display, Start Sound, End Sound, Reset Setting.
 - **Camera:** Switches from camcorder to camera.
3. Press  to save the settings.
 4. Press  **REC** to begin recording. Press the left soft key  **Pause** or  **STOP**.
 5. Press the right soft key  **Erase** or the left soft key  **Save**.
 6. To exit the camcorder, press the  key.

Note: If you receive an incoming call while using your camcorder, the video recording is stopped. You will be presented with the call Ignore / Accept screen. If you ignore the call, then you are given the choice to Save, Send or Erase the video. If you accept the call, then your video is auto-saved and the camcorder application exits in the background.

Note: If the battery level becomes too low while you are recording, the recording is stopped and the video is auto-saved. The low battery indicator will be displayed and you will exit from the camcorder application. If your battery is too low then the phone will power down without saving the video.

Note: If you receive a text message, a multi-media message or a voice mail while you are recording, the video recording is stopped. You are given the choice to View Now or View Later. If you choose later, you are given the chance to Save, Send or Erase the video. If you want to view the message now, the video is auto-saved and the camera application exits in the background.

My FLIX

This menu allows you to review the videos you have taken or downloaded and stored into your phone and / or microSD™ / TransFlash™ card.

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press  **Get PIX & FLIX**.
2. Press  **My FLIX**.
3. Press the navigation key to highlight the desired video clip and press  **PLAY** to play the selected video.
4. After playing the video, press the **CLR** key  to return to the thumbnail view.
5. Press the right soft key  **Options** for the following options. Highlight an option and press  to make your selection.
 - Send
 - To PIX Place
 - Get V CAST Video
 - Set As Wallpaper
 - Rename
 - Move
 - Lock
 - Erase
 - Erase All
 - FLIX Info

PIX Place

Send a PIX to your online album.

Note: You must first setup your account on the Verizon Wireless website: www.verizonwireless.com before establishing a connection.

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press  **Get PIX & FLIX**.
2. Highlight **PIX Place** and press . The PIX Place sign-on screen displays.
3. Enter your **Mobile Number** and **Password**. Use the navigation key to highlight **LOGIN** and press . You are now connected to your online album.

Get Fun & Games

Select from several fun and interesting applications or a broad category of games that you can play on your phone.

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press  **Get Fun & Games**.
2. Press  **Get New App**.
3. Use the navigation keys to make a selection and press .
4. Choose the charge Either Subscription or Unlimited, then press . Follow in screen prompts to apply.

Note: Some games include VibeTonz vibration feedback, similar to PC and console games, offering enhanced realism. Visit www.vibetonz.com to see the list of VibeTonz-enhanced mobile games for your phone.

Get News & Info

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press  **Get News & Info**.
2. The browser is launched and a pop up screen with available applications is displayed.
3. Use the navigation key to browse the categories.
4. Once the desired category is highlighted, press  to enter the category list.

When you use Get News & Info, some of the keys operate differently than during a normal phone call.

It presents on-screen items in any of the following ways:

- Text or numeric input
- Links (embedded in content)
- Numbered options (some options may not be numbered)
- Simple text

You can utilize the options or links by using the soft keys.

Get Going

Download applications that keep you in touch with the world, keep you organized, and help you find the coolest spots.

1. In standby mode, press  **MENU**, use the left navigation key to highlight  **GET IT NOW**. Press  **Get Going**.
2. **Get New App.** is highlighted. Press .
3. Highlight the application you wish to download and press .
4. Follow on screen subscription prompts and press . The download process begins.
5. At the "App installed successfully. Would you like to run it?" prompt, press **Yes** to launch application, or **No** to return to category list.

Note: The GET GOING menu will display all downloaded applications, with the most current download first.

Get Extras

Get Extras is a backup assistant for your Address Book. Get Extras saves your address book entries to a database to protect them in the event that your phone is damaged and allows them to be retrieved at a later date.

Section 10: Tools

Topics Covered

- Voice Commands
 - Calculator
 - Calendar
 - Alarm Clock
 - World Clock
 - Stop Watch
 - Notepad
-

The topics covered in this section allow you to schedule appointments, view the calendar, set an alarm, view time zones, take notes, and perform simple math calculations.

Voice Commands

For more information see, "VoiceSignal™" on page 39.

Calculator

You can perform calculations, including addition, subtraction, multiplication and division using your phone.

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**,  **Calculator**,  **Normal**. The Calculator opens.
2. Enter the first number in your equation using the keypad. (Numbers can be up to nine digits long.)
3. Press the right soft key  **Operator** to display a pop-up menu which allows you to enter a Parenthesis or Power if desired. Press the left soft key  **Clear** or  to clear all data entered.
4. Press  to change the sign for a number to a negative.
5. Press the  to add a decimal point.
6. Use the navigation keys to set the type of calculation that you wish to perform. Your choices are as follows:
 - **Up key:** [+]
Addition
 - **Down key:** [-]
Subtraction
 - **Right key:** [x]
Multiplication
 - **Left key:** [÷]
Division
7. Use the keypad to enter the second number into your equation.

8. Press  to perform the calculation and view the result.

Tip

Calculates the tip and determine how much each person should pay for the meal.

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**,  **Calculator**,  **Tip**. The **Tip Calculator** opens.
2. Populate the following fields:
 - **Bill**: enter the amount of the bill.
 - **Tip**: enter the tip percentage.
 - **# Paying**: enter the amount of people paying.

Note: Press the  key to enter a decimal point.

3. The tip is automatically calculated in the section below.

Converter

The **Conversion** menu provides the following conversion categories:

- Temperature
- Length
- Weight
- Area
- Volume
- Currency

To convert any of the above categories, do the following:

1. Scroll to the conversion feature you wish to use and press the  key.
2. Use the **Left** or **Right** navigation keys to select the From units of money or measure for the quantity you want converted.
3. Enter the quantity you want converted in the text box.

Note: Press the  key to enter a decimal point.

Use the Left or Right navigation keys to select the To units of money or measure for the quantity you want converted.

Calendar

Schedule up to eight events for any day by indicating each event's start and end time. Set alarms for events so that you can be alerted before an event takes place. Events scheduled for future dates automatically appear on your Today events schedule for the present day.

Add a new event

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**  **Calendar**. The calendar appears in the display with the current date highlighted.
2. To view available options, press the right soft key  **Options**. A pop-up menu appears in the display that contains the menu items.
 - **Weekly:** View the current week.

- **Go To Date:** Go to any date that you specify.
 - **Go to Today:** View today's events.
 - **Erase Old:** Select a past event to delete.
 - **Erase All:** Delete all events in your calendar
3. Press the left soft key  **Add** to add a new event.
 4. The **Appointment name** field is highlighted. Enter the name and use the down navigation key to move to the following fields:
 - **Start Date:** Enter the start date for the event.
 - **Start Time:** Enter the start time for the event.
 - **am/pm:** Select from am or pm for the start time.
 - **End Date:** Enter the end date for the event.
 - **End Time:** Enter the end time for the event.
 - **am/pm:** Select from am or pm for the end time.
 - **Time Zone:** Enter the time zone you wish your event to reflect.

Note: Each time zone is listed as both a standard time zone and a daylight time zone. For example, if you are in the Central Time zone, you would enter CDT (Central Daylight Time) if you are on Daylight Savings time, or CST (Central Standard Time) if you are not.

- **Recurrence:** Select the frequency of the event.
 - **Alert:** Sets the alarm for the event. Select from Tone, Vibrate, or Light Only.
 - **Reminder:** Set a reminder up to one day before the event.
 - **Alert Time:** Set the Alert Time to sound before the event takes place.
5. Fill in and select event details using the navigation keys and the alpha-numeric keypad.

6. Press . The event is saved.

View an event

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**  **Calendar**.
2. A calendar appears in the display with the current date highlighted.
3. Use the navigation keys to highlight the date containing the event that you wish to view. Press the right soft key  **Options**.

Tip: Use the volume key to move between months in the calendar.

4. In the pop-up menu that appears in the display, use the navigation key to highlight **Go To Date**, then press .
5. Enter the desired date in the box, then press . The month that you entered appears in the display with the event date highlighted.
6. Press  **VIEW** to view event details for the date.
7. To edit the event, press the left soft key  **Edit**. Make changes, then press  **SAVE**.
8. Press the right soft key  **Options**. A pop-up menu appears in the display.
9. To erase the current event, press  **Erase**. A pop-up menu appears with **Yes** highlighted. press  to erase, or highlight **No** to cancel.

10. To see the selected date in a month view, press  **Monthly**.
11. To see the selected date in a week view, press  **Weekly**.

Alarm Clock

Your phone has an alarm clock that can be set to go off once, or recur daily at a specific time. Once set, the alarm clock is easy to change or turn off.

Set An Alarm

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**  **Alarm Clock**. The **Alarm Clock** menu displays with the **Alarm 1** highlighted.
2. The following options appear in the display:
 - **Alarm 1**
 - **Alarm 2**
 - **Alarm 3**
3. Use the navigation key to highlight the alarm that you wish to enable, then press . The Set Alarm (1, 2, or 3 depending on your selection) screen appears in the display.
4. The Alarm field is highlighted. Use the left/right navigation keys to select **On** or **Off**.
5. Press the down navigation key to highlight the **Time** field, then enter the time that you wish for the alarm to sound.

6. Press the down navigation key once to highlight the **am/pm** field. Use the left/right navigation keys to select **am** or **pm**.
7. Press the down navigation key once to highlight the **Frequency** field. Use the left/right navigation keys to set the frequency (occurrence) of the alarm. Below lists and defines the options for this field.
 - **Once**: The alarm sounds only once, at the time specified.
 - **Daily**: The alarm sounds every day at the time specified.
 - **Mon-Fri**: The alarm sounds Monday through Friday at the time specified.
 - **Weekends**: The alarm sounds Saturday through Sunday at the time specified.
8. Press the down navigation key once to highlight the first **Ringer** field. Use the left/right navigation keys to set the ringer to Tone, Vibrate, or Light Only.
9. If you selected Tone, press the down navigation key again to highlight the second field. Use the left/right navigation keys to set the alert tone to VZW Default Tone, or select a tone from your My Ringtones or My Sounds folders.
10. When all fields have correct information entered, press  **SAVE** to save your settings.

Disable an alarm before it sounds

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**  **Alarm Clock**. The **Alarm Clock** menu displays with the **Alarm 1** highlighted.

2. Use the navigation keys to highlight the alarm you wish to disable, then press the right soft key  **Options**. A pop-up menu appears in the display.
3. Press  **Off** to turn the highlighted alarm off. Press  **Reset Alarm** to reset the highlighted alarm or press  **Reset All** to reset all of the alarms.

Snooze

When an alarm sounds, a menu screen displays that allows you to either turn the alarm off or to have the alarm ring again after 5 minutes. This is called Snooze.

To use this feature follow these steps:

1. Set one of your phone's 3 alarms. For more information about setting an alarm, see "Set An Alarm" on page 161.
2. When an alarm sounds, use the up/down navigation key to highlight **Snooze** or **Dismiss**. To snooze, highlight **Snooze** and press  to set it to ring again after 5 minutes. Or, highlight **Dismiss** to turn the alarm off completely. The alarm turns off and the standby screen displays.

World Clock

World Clock allows you to view the time of day or night in any part of the world.

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**  **World Clock**.
2. Use the left soft key  **Cities** to display the 46 supported cities. Press  to save your entry.

3. Press the right soft key  **Options** to view the following options:
 - **Set As Local Time:** Sets the time according to the city chosen in the Cities field.
 - **DST On:** Sets the Daylight Savings time option.
4. You can scroll through other cities by pressing the navigation keys.
5. Press  to return to standby mode.

Stop Watch

This feature allows you to use a stopwatch. Press the  **START** to start the stopwatch. Press  **STOP** to stop stopwatch. Press the right soft key  **Reset** to erase recorded stopwatch time.

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**  **Stop Watch**. The **Stop Watch** appears in the display.
2. Press the  **START** to start the stopwatch.
3. Press  **STOP** to stop stopwatch.
4. Press the right soft key  **Reset** to erase recorded stopwatch time.

Notepad

Create and store notes in Notepad. Return to Notepad anytime to review and edit your notes.

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**  **Notepad**.
2. If you have any stored notes, they appear as a list in the display. If this is your first time in Notepad, **No Note** displays.
3. To add a new memo, press the left soft key  **Add**, then enter the memo using the keypad.
4. While entering a memo, press the left soft key  **Abc**, to display a pop-up menu with the following text entry modes
 - **Word**
 - **Abc**
 - **ABC**
 - **123**
 - **Symbols**
5. Use the navigation keys to select the other available text entry modes of 123, Word, and Symbol, or press  to exit the pop-up menu.
6. When you're finished entering details for the note, press . The note is saved.

Review, Add, Edit, and Erase Memos

1. In standby mode, press  **MENU**, then press the right navigation key to  **SETTINGS & TOOLS**. Press  **Tools**. The **Notepad** menu opens. If you have any stored notes, they appear as a list in the display.
2. With a memo highlighted, press the right soft key  **Options**. A pop-up menu with the options listed in the following table appears in the display:
 - **Edit**: Edit the note currently highlighted or appearing in the display.
 - **Erase**: Erase the note currently highlighted or appearing in the display.
 - **Erase All**: Erase all notes.
 - **Lock/Unlock**: Locks messages. When a message is locked it cannot be deleted until it is unlocked.
3. Use the navigation keys to highlight an option or press  to exit the pop-up menu.
4. Press  to perform the highlighted option's function.

Section 11: Mobile Web

Topics Covered

- Mobile Web
 - Launching Mobile Web
 - Exit Mobile Web
 - Navigate the Web
 - Mobile Web Soft keys
 - Links
 - Place a Call While Using Mobile Web
-

This section outlines the available mobile web options.

Mobile Web

Mobile Web allows you to surf the web from your wireless phone.

If you receive a call while using Mobile Web, the web session is suspended during the call. Once the call ends, your Mobile Web session resumes where you left off.

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhanced Services Area.

Any time the service indicator icon is visible, you are connected to the Internet and billed accordingly. Rates and prices vary according to your service contract. For further information on billing contact Verizon Wireless.

Launching Mobile Web

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhanced Services Area.

1. In standby mode, press the up navigation key. Mobile Web and a list of categories (representing one or more web sites) appears in the display.
2. Use the navigation key to browse the categories.
3. Once the desired category is highlighted, press  to enter the category list.

Exit Mobile Web

To exit the Mobile Web, press the  key.

Navigate the Web

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhanced Services Area.

When you use Mobile Web, some of the keys operate differently than during a normal phone call.

Mobile Web presents on-screen items in any of the following ways:

- Text or numeric input
- Links (embedded in content)
- Numbered options (some options may not be numbered)
- Simple text

You can act on the options or links by using the soft keys.

Mobile Web Soft Keys

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhanced Services Area.

At the bottom of the Mobile Web display contains the browser commands. The left  and right  soft keys on the keypad are used to perform the commands in the display. These are called “soft keys” because their function changes depending where you are in the application.

How Mobile Web keys work

The following table lists Mobile Web keys and functions.



Navigation Key: Use the navigation key to browse lists and highlight options.



CLR Key: A browser back-up key. Press once to back up one page. Press and hold to go back to Mobile Web home page.

Press to clear the last number, letter, or symbol entered. Press and hold to completely clear the display.



Asterisk/Shift Key: Press before entering text to enable upper case characters (in Abc mode).



O/Next Key: Press to enter a zero (0), or to display another word in the dictionary when in Word entry mode.



Pound/Space Key: Press to insert a space when entering text.



Numbers 1 - 9: Use the number keys to select items in a menu if they are numbered.



END Key: Press to exit Mobile Web and return the phone to standby mode.



Left Soft Key: Press the left soft key to go to the highlighted web link and/or perform the function above it in the display.



Right Soft Key: The right soft key is the Menu key. Press this key to display a pop-up menu with several options.



SEND Key: Press to dial a highlighted number.

Links

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhanced Services Area.

Links can serve several purposes, such as jumping to a different page, to a different site, or initiating a phone call. Links are underlined (___). Normally, the left soft key  is used to select a highlighted link.

Place a Call While Using Mobile Web

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhanced Services Area.

You can place a call while using Mobile Web if the website supports this feature. Press the appropriate soft key to call the number. In most cases you can also press  to call the number. The Internet connection terminates when you initiate the call. After you end the call, your phone returns to standby mode.

Section 12: Health and Safety Information

Topics Covered

- Health and Safety Information
 - Consumer Information on Wireless Phones
 - Road Safety
 - Operating Environment
 - Using Your Phone Near Other Electronic Devices
 - Potentially Explosive Environments
 - Emergency Calls
 - FCC Notice and Cautions
 - Other Important Safety Information
 - Product Performance
 - Availability of Various Features/Ring Tones
 - Battery Standby and Talk Time
 - Battery Precautions
 - Care and Maintenance
-

This section outlines the safety precautions associated with using your phone. These safety precautions should be followed to safely use your phone

Health and Safety Information

Exposure to Radio Frequency (RF) Signals

Certification Information (SAR)

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. government. These FCC exposure limits are derived from the recommendations of two expert organizations, the National Council on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The exposure limit set by the FCC for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg). The FCC exposure limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined

at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each model phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC. For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the handset a minimum of 1.5 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

The FCC has granted an Equipment Authorization for this mobile phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. The maximum SAR values for this model phone as reported to the FCC are:

- **Verizon Wireless mode:**

- Head: 1.42 W/kg
- Body-worn: 1.37 W/kg

SAR information on this and other model phones can be viewed on-line at www.fcc.gov/oet/fccid. To find information that pertains to a particular model phone, this site uses the phone FCC ID number which is usually printed somewhere on the case of the phone. Sometimes

it may be necessary to remove the battery pack to find the number. Once you have the FCC ID number for a particular phone, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone. Additional product specific SAR information can also be obtained at www.fcc.gov/cgb/sar.

UL Certified Travel Adapter

The Travel Adapter for this phone has met UL 1310 safety requirements. Please adhere to the following safety instructions per UL guidelines.

**FAILURE TO FOLLOW THE INSTRUCTIONS
OUTLINED MAY LEAD TO SERIOUS PERSONAL
INJURY AND POSSIBLE PROPERTY DAMAGE
IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE
INSTRUCTIONS.**

**DANGER - TO REDUCE THE RISK OF FIRE OR
ELECTRIC SHOCK, CAREFULLY FOLLOW THESE
INSTRUCTIONS.**

**FOR CONNECTION TO A SUPPLY NOT IN THE U.S.A.,
USE AN ATTACHMENT PLUG ADAPTOR OF
THE PROPER CONFIGURATION FOR THE POWER
OUTLET.**

Consumer Information on Wireless Phones

The U.S. Food and Drug Administration (FDA) has published a series of Questions and Answers for consumers relating to radio frequency (RF) exposure from wireless phones. The FDA publication includes the following information:

What kinds of phones are the subject of this update?

The term wireless phone refers here to hand-held wireless phones with built-in antennas, often called "cell," "mobile," or "PCS" phones. These types of wireless phones can expose the user to measurable radio frequency energy (RF) because of the short distance between the phone and the user's head. These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures well within the FCC's compliance limits.

Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radio frequency energy (RF) in the microwave range

while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

What is FDA's role concerning the safety of wireless phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radio frequency energy (RF) at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;

- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health.

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Safety and Health Administration
- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. FCC relies on FDA and other health agencies for safety questions about wireless phones.

FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are

thus not the primary subject of the safety questions discussed in this document.

What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radio frequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phones RF exposures. However, none of the studies can answer questions about long-term

exposures, since the average period of phone use in these studies was around three years.

What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but ten or more years' follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop - if they do - may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

What is FDA doing to find out more about the possible health effects of wireless phone RF?

FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radio frequency energy (RF).

FDA has been a leading participant in the World Health Organization international Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues.

FDA and Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

What steps can I take to reduce my exposure to radio frequency energy from my wireless phone?

If there is a risk from these products - and at this point we do not know that there is - it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radio frequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

- If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna.

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radio frequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

Do hands-free kits for wireless phones reduce risks from exposure to RF emissions?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that hands-free kits reduce risks. Hands-free kits can be used with wireless phones for convenience and comfort. These systems reduce the absorption of RF energy in the head because the phone, which is the source of the RF emissions, will not be placed against the head. On the other hand, if the phone is mounted against the waist or other part of the body during use, then that part of the body will absorb more RF energy. Wireless phones marketed in the U.S. are required to meet safety requirements regardless of whether they are used against the head or against the body. Either configuration should result in compliance with the safety limit.

Do wireless phone accessories that claim to shield the head from RF radiation work?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that accessories that claim to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone. Studies have shown that these products generally do not work as advertised. Unlike "hand-free" kits, these so-called "shields" may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption. In February 2002, the Federal Trade Commission (FTC) charged two companies

that sold devices that claimed to protect wireless phone users from radiation with making false and unsubstantiated claims. According to FTC, these defendants lacked a reasonable basis to substantiate their claim.

What about wireless phone interference with medical equipment?

Radio frequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI. FDA has tested wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a compatible phone and a compatible hearing aid at the same time. This standard was approved by the IEEE in 2000.

FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct

testing to assess the interference and work to resolve the problem.

Additional information on the safety of RF exposures from various sources can be obtained from the following organizations:

- FCC RF Safety Program:
<http://www.fcc.gov/oet/rfsafety/>
- Environmental Protection Agency (EPA):
<http://www.epa.gov/radiation/>
- Occupational Safety and health Administration's (OSHA):
<http://www.osha.gov/SLTC/radiofrequencyradiation/index.html>
- National institute for Occupational Safety and health (NIOSH):
<http://www.cdc.gov/niosh/topics/emf/>
- World health Organization (WHO):
<http://www.who.int/peh-emf/>
- International Commission on Non-Ionizing Radiation Protection:
<http://www.icnirp.de>
- National Radiation Protection Board (UK):
<http://www.hpa.org.uk/radiation/>
- Updated 7/16/2003: US Food and Drug Administration
<http://www.fda.gov/cellphones>

Road Safety

Your wireless phone gives you the powerful ability to communicate by voice, almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. When using your wireless phone behind the wheel of a

car, practice good common sense and remember the following tips:

1. Get to know your wireless phone and its features, such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.
2. When available, use a hands-free device. If possible, add an additional layer of convenience and safety to your wireless phone with one of the many hands free accessories available today.
3. Position your wireless phone within easy reach. Be able to access your wireless phone without removing your eyes from the road. If you get an incoming call at an inconvenient time, let your voicemail answer it for you.
4. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice and even heavy traffic can be hazardous.
5. Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or flipping through your address book takes attention away from your primary responsibility, driving safely.
6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.

7. Do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that have the potential to divert your attention from the road.
8. Use your wireless phone to call for help. Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies. Remember, it is a free call on your wireless phone!
9. Use your wireless phone to help others in emergencies. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.

10. Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency number.

"The wireless industry reminds you to use your phone safely when driving."

For more information, please call 1-888-901-SAFE, or visit our web-site www.wow-com.com

Provided by the Cellular Telecommunications & Internet Association.

Operating Environment

Remember to follow any special regulations in force in any area and always switch your phone off whenever it is forbidden to use it, or when it may cause interference or danger. When connecting the phone or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and for the safety of personnel, it is recommended that the equipment should only be used in the normal operating position (held to your ear with the antenna pointing over your shoulder if you are using an external antenna).

Using Your Phone Near Other Electronic Devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. Consult the manufacturer to discuss alternatives.

Pacemakers

Pacemaker manufacturers recommend that a minimum distance of 15 cm (6 inches) be maintained between a wireless phone and a pacemaker to avoid potential interference with the pacemaker.

These recommendations are consistent with the independent research and recommendations of Wireless Technology Research.

Persons with pacemakers:

- should always keep the phone more than 15 cm (6 inches) from their pacemaker when the phone is switched on.
- should not carry the phone in a breast pocket.
- should use the ear opposite the pacemaker to minimize potential interference.

If you have any reason to suspect that interference is taking place, switch your phone off immediately.

Hearing Aid Compatibility with Mobile Phones

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this

interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better / higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better / higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Other Medical Devices

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your phone off in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Switch your phone off in any facility where posted notices require you to do so.

Potentially Explosive Environments

Switch your phone off when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Users are advised to switch the phone off while at a refueling point (service station). Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots

(fuel storage and distribution areas), chemical plants or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, wireless and landline networks as well as user-programmed functions, which cannot guarantee connection in all conditions. Therefore, you should never rely solely on any wireless phone for essential communications (medical emergencies, for example).

Remember, to make or receive any calls the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks or when certain network services and / or phone features are in use. Check with local service providers.

To make an emergency call:

1. If the phone is not on, switch it on.
2. Key in the emergency number for your present location (for example, 911 or other official emergency number).
Emergency numbers vary by location.
3. Press the Send key.

If certain features are in use (call barring, for example), you may first need to deactivate those features before you can make an emergency call. Consult this document and your local cellular service provider.

When making an emergency call, remember to give all the necessary information as accurately as possible.

Remember that your phone may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

Restricting Children's access to your Phone

Your phone is not a toy. Children should not be allowed to play with it because they could hurt themselves and others, damage the phone or make calls that increase your phone bill.

FCC Notice and Cautions

FCC Notice

The phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269, Attn: Publication Sales Division.

Cautions

Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment, and void your authority to operate this equipment. Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and void the phone warranty if said accessories cause damage or a defect to the phone.

Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.

Other Important Safety Information

- Only qualified personnel should service the phone or install the phone in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Check regularly that all wireless phone equipment in your vehicle is mounted and operating properly.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as the phone, its parts or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including both installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Switch your phone off before boarding an aircraft. The use of wireless phone in aircraft is illegal and may be dangerous to the aircraft's operation.

- Failure to observe these instructions may lead to the suspension or denial of telephone services to the offender, or legal action, or both.

Product Performance

Getting the Most Out of Your Signal Reception

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current signal strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal.

If you're inside a building, being near a window may give you better reception.

Understanding the Power Save Feature

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. If your phone is active, it periodically rechecks service availability or you can check it yourself by pressing any key.

Anytime the Power Save feature is activated, a message displays on the screen. When a signal is found, your phone returns to standby mode.

Understanding How Your Phone Operates

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.006 watts to 0.2 watts in digital mode.

Maintaining Your Phone's Peak Performance

For the best care of your phone, only authorized personnel should service your phone and accessories. Faulty service may void the warranty.

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- If your phone is equipped with an external antenna, hold the phone with the antenna raised, fully-extended and over your shoulder.
- Do not hold, bend or twist the phone's antenna, if applicable.
- Do not use the phone if the antenna is damaged.
- If your phone is equipped with an internal antenna, obstructing the internal antenna could inhibit call performance.
- Speak directly into the phone's receiver.
- Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it is inoperable, call Customer Care for service.

Availability of Various Features/Ring Tones

Many services and features are network dependent and may require additional subscription and /or usage charges. Not all features are available for purchase or use in all areas. Downloadable Ring Tones may be available at an additional cost. Other conditions and restrictions may apply. See your service provider for additional information.

Battery Standby and Talk Time

Standby and talk times will vary depending on phone usage patterns and conditions. Battery power consumption depends on factors such as network configuration, signal strength, operating temperature, features selected, frequency of calls, and voice, data, and other application usage patterns.

Battery Precautions

- Avoid dropping the cell phone. Dropping it, especially on a hard surface, can potentially cause damage to the phone and battery. If you suspect damage to the phone or battery, take it to a service center for inspection.
- Never use any charger or battery that is damaged in any way.
- Use the battery only for its intended purpose.
- If you use the phone near the network's base station, it uses less power; talk and standby time are greatly affected by the signal strength on the cellular network and the parameters set by the network operator.
- Follow battery usage, storage and charging guidelines found in the user's guide.
- Battery charging time depends on the remaining battery charge and the type of battery and charger used. The battery can be charged and discharged hundreds of times, but it will gradually wear out. When the operation time (talk time and standby time) is noticeably shorter than normal, it is time to buy a new battery.
- If left unused, a fully charged battery will discharge itself over time.
- Use only Samsung-approved batteries and recharge your battery only with Samsung-approved chargers. When a charger is not in use, disconnect it from the power source. Do not leave

the battery connected to a charger for more than a week, since overcharging may shorten its life.

- Do not use incompatible cell phone batteries and chargers. Some Web sites and second-hand dealers, not associated with reputable manufacturers and carriers, might be selling incompatible or even counterfeit batteries and chargers. Consumers should purchase manufacturer or carrier recommended products and accessories. If unsure about whether a replacement battery or charger is compatible, contact the manufacturer of the battery or charger.
- Extreme temperatures will affect the charging capacity of your battery: it may require cooling or warming first.
- Do not leave the battery in hot or cold places, such as in a car in summer or winter conditions, as you will reduce the capacity and lifetime of the battery. Always try to keep the battery at room temperature. A phone with a hot or cold battery may temporarily not work, even when the battery is fully charged. Li-ion batteries are particularly affected by temperatures below 0 °C (32 °F).
- Do not place the phone in areas that may get very hot, such as on or near a cooking surface, cooking appliance, iron, or radiator.
- Do not get your phone or battery wet. Even though they will dry and appear to operate normally, the circuitry could slowly corrode and pose a safety hazard.
- Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object (coin, clip or pen) causes a direct connection between the + and - terminals of the battery (metal strips on the battery), for example when you carry a spare battery in a pocket or bag. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting.
- Do not permit a battery out of the phone to come in contact with metal objects, such as coins, keys or jewelry.
- Do not crush, puncture or put a high degree of pressure on the battery as this can cause an internal short-circuit, resulting in overheating.

- Dispose of used batteries in accordance with local regulations. In some areas, the disposal of batteries in household or business trash may be prohibited. For safe disposal options for Li-Ion batteries, contact your nearest Samsung authorized service center. Always recycle. Do not dispose of batteries in a fire.

Non-Supported Battery

WARNING TO USER: If you have received the message on your phone "non supported battery, see user guide," then your phone has detected a nonsupported battery. You must press "OK" on your phone to be able to continue usage. Once you have received this detection message, the handset will not charge the non supported battery. Your handset will only charge a supported battery. Please call *611 for information regarding resolving this issue.

Care and Maintenance

Your phone is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years

- Keep the phone and all its parts and accessories out of the reach of small children.
- Keep the phone dry. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits.
- Do not use the phone with a wet hand. Doing so may cause an electric shock to you or damage to the phone.
- Do not use or store the phone in dusty, dirty areas, as its moving parts may be damaged.

- Do not store the phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the phone in cold areas. When the phone warms up to its normal operating temperature, moisture can form inside the phone, which may damage the phone's electronic circuit boards.
- Do not drop, knock or shake the phone. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the phone. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.
- Do not paint the phone. Paint can clog the device's moving parts and prevent proper operation.
- Do not put the phone in or on heating devices, such as a microwave oven, a stove or a radiator. The phone may explode when overheated.
- If your phone has an external antenna, use only the supplied or an approved replacement antenna. Unauthorized antennas or modified accessories may damage the phone and violate regulations governing radio devices.
- If the phone, battery, charger or any accessory is not working properly, take it to your nearest qualified service facility. The personnel there will assist you, and if necessary, arrange for service.

Section 13: Warranty Information

Topics Covered

- Standard Limited Warranty
-

This section explains the warranty information for your new phone.

Standard Limited Warranty

What is Covered and For How Long? SAMSUNG

TELECOMMUNICATIONS AMERICA, L.P. ("SAMSUNG") warrants to the original purchaser ("Purchaser") that SAMSUNG's Phones and accessories ("Products") are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase and continuing for the following specified period of time after that date:

Phone	1 Year
Batteries	1 Year
Leather Case / Pouch	90 Days
Holster	90 Days
Other Phone Accessories	1 Year

What is Not Covered? This Limited Warranty is conditioned upon proper use of Product by Purchaser. This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abuse, neglect, unusual physical, electrical or electromechanical stress, or modification of any part of Product, including antenna, or cosmetic damage; (b) equipment that has the serial number removed or made illegible; (c) any plastic surfaces or other externally exposed parts that are scratched or damaged due to normal use; (d) malfunctions resulting from the use of Product in conjunction with accessories, products, or

ancillary / peripheral equipment not furnished or approved by SAMSUNG; (e) defects or damage from improper testing, operation, maintenance, installation, or adjustment; (f) installation, maintenance, and service of Product, or (g) Product used or purchased outside the United States or Canada. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

What are SAMSUNG's Obligations? During the applicable warranty period, SAMSUNG will repair or replace, at SAMSUNG's sole option, without charge to Purchaser, any defective component part of Product. To obtain service under this Limited Warranty, Purchaser must return Product to an authorized phone service facility in an adequate container for shipping, accompanied by Purchaser's sales receipt or comparable substitute proof of sale showing the date of purchase, the serial number of Product and the sellers' name and address. To obtain assistance on where to deliver the Product, call Samsung Customer Care at 1-888-987-4357. Upon receipt, SAMSUNG will promptly repair or replace the defective Product. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product or replace Product with a rebuilt, reconditioned or new Product. Repaired / replaced leather cases, pouches and holsters will be

warranted for a period of ninety (90) days. All other repaired / replaced Product will be warranted for a period equal to the remainder of the original Limited Warranty on the original Product or for 90 days, whichever is longer. All replaced parts, components, boards and equipment shall become the property of SAMSUNG. If SAMSUNG determines that any Product is not covered by this Limited Warranty, Purchaser must pay all parts, shipping, and labor charges for the repair or return of such Product.

WHAT ARE THE LIMITS ON SAMSUNG'S WARRANTY/LIABILITY? EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED HEREIN, PURCHASER TAKES THE PRODUCT "AS IS," AND SAMSUNG MAKES NO WARRANTY OR REPRESENTATION AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO:

- THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE;
- WARRANTIES OF TITLE OR NON-INFRINGEMENT;
- DESIGN, CONDITION, QUALITY, OR PERFORMANCE OF THE PRODUCT;
- THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR
- COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO.

NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN

EXPRESS WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. ALL IMPLIED WARRANTIES AND CONDITIONS THAT MAY ARISE BY OPERATION OF LAW, INCLUDING IF APPLICABLE THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED TO THE SAME DURATION OF TIME AS THE EXPRESS WRITTEN WARRANTY STATED HEREIN. SOME STATES / PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND

RESULTING FROM THE PURCHASE, USE, OR MISUSE OF, OR INABILITY TO USE THE PRODUCT OR ARISING DIRECTLY OR INDIRECTLY FROM THE USE OR LOSS OF USE OF THE PRODUCT OR FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL, CONSEQUENTIAL OR SIMILAR DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS, OR FOR DAMAGES ARISING FROM ANY TORT (INCLUDING NEGLIGENCE OR GROSS NEGLIGENCE) OR FAULT COMMITTED BY SAMSUNG, ITS AGENTS OR EMPLOYEES, OR FOR ANY BREACH OF CONTRACT OR FOR ANY CLAIM BROUGHT AGAINST PURCHASER BY ANY OTHER PARTY. SOME STATES / PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO

YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE / PROVINCE TO PROVINCE. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT AND STATES PURCHASER'S EXCLUSIVE REMEDY. IF ANY PORTION OF THIS LIMITED WARRANTY IS HELD ILLEGAL OR UNENFORCEABLE BY REASON OF ANY LAW, SUCH PARTIAL ILLEGALITY OR UNENFORCEABILITY SHALL NOT AFFECT THE ENFORCEABILITY FOR THE REMAINDER OF THIS LIMITED WARRANTY WHICH PURCHASER ACKNOWLEDGES IS AND WILL ALWAYS BE CONSTRUED TO BE LIMITED BY ITS TERMS OR AS LIMITED AS THE LAW PERMITS. THE PARTIES UNDERSTAND THAT THE PURCHASER MAY USE THIRD-PARTY SOFTWARE OR EQUIPMENT IN CONJUNCTION WITH THE PRODUCT. SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRDPARTY SOFTWARE OR EQUIPMENT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE, INCLUDING THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT. THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY

OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT LIE SOLELY WITH THE PURCHASER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT, AS THE CASE MAY BE.

This Limited Warranty allocates risk of Product failure between Purchaser and SAMSUNG, and SAMSUNG's Product pricing reflects this allocation of risk and the limitations of liability contained in this Limited Warranty. The agents, employees, distributors, and dealers of SAMSUNG are not authorized to make modifications to this Limited Warranty, or make additional warranties binding on SAMSUNG. Accordingly, additional statements such as dealer advertising or presentation, whether oral or written, do not constitute warranties by SAMSUNG and should not be relied upon.

Samsung Telecommunications America, L.P.

1301 East Lookout Drive

Richardson, Texas 75082

Phone: 1-800-SAMSUNG

Phone: 1-888-987-HELP (4357)

©2006 Samsung Telecommunications America, L.P. All rights reserved.

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice.

Printed in South Korea

Index

Numerics

1-touch dialing 79

2-touch dialing 79

3G protocol icon 22

3-touch dialing 79

911, notes about 117

A

Adding a New Contact

Entry 69

Alarm clock

icon 24

snooze 163

turn off the alarm 162

Answer options 119

Auto answer 119

Auto answer icon 24

Auto retry 120

B

Backup to last menu 52

Battery 26

charging 28

indicator 28

installing 27

removing 27

strength icon 23

Bluetooth 123

about 123

icons 23

C

Calendar

add a new event 158

Call Functions 31

answering a call 33

Recent Calls 33

roaming 37

Call history

calls using 35

definition 33

deleting entry 36

icons 35

new contact 35

updating existing

contact 35

Call restriction 121

Camcorder

camcorder key 16

recording video 148

Camera

camera key 16

taking pictures 146

Change lock code 115

Changing Message

Settings 95

Chat 99

Clear key 20

Clock Format 110

Command Keys 19

Contact List

finding a contact entry 76

Contacts 67

- adding a new contact entry 69
- deleting a contact entry 77
- editing an existing contact entry 77
- speed dialing 78
- wait pause & 2-second pause 72

Creating and Sending PIX/

FLIX Messages 85

Creating and Sending TXT Messages 83

D

Dialing

- one-touch 79
- three-touch 79
- two-touch 79

Dialing Font 111

Disable alarm 162

Display 106

- animation 110
- backlight 108
- banner 107
- language 112
- screen icons 22

Display Theme 109

Downloading Music 132

Draft messages 92

Drafts folder 92

E

E-Mail 97

End key 20

Entering Text 61

- changing text entry mode 62
- entering numbers 66
- entering symbols 65
- entering upper and lower case 64
- using Word mode 63

F

Finding a Contacts Entry 76

Finding My Phone Number 80

Folder

- drafts 92
- inbox 89

G

Get It Now 130

Get New PIX 145

Get News & Info 152

Get PIX & FLIX 142

Get Tunes & Tones 131

Getting Started 9

- understanding this user manual 11

GPS icons 23

Groups

- creating 74
- move entries from/to 73

- send messages to 74
- send PIX/FLIX msg to 75
- viewing 73

H

Hard pause 72

Health and Safety Information 173

I

Icons

- alarm on 24
- alarm only 24
- battery strength 23
- display 22
- dormant 23
- signal strength 22
- silent mode 24
- TTY 23

Inbox folder 89

Indicator

- calendar appointment 24
- missed calls 24
- new message 24
- no service 23
- roaming 22
- signal strength 22
- speakerphone 24
- stand alone 22

Installing battery 27

Instant Messaging 98

In-use menu 53

L

Language setting 112

Left soft key 19

Links 171

Lock code, changing 115

Lock Mode 117

- placing an emergency call 117

Lock phone 114

M

Making a call 32

Manage Music 139

Memory Card Storage 29

Memos, editing 166

Menu Navigation 51

- menu outline 54

Menu shortcuts 52

Menu, in-use option 53

Message folder

- drafts 92
- inbox 89

Messages, receive in call 88

Messaging 81

- types of messages 82

microSD/TransFlash Card

- formatting 131

Mobile IM 98

Mobile Web 167

- exit 168
- launch Mobile Web 168
- links 171
- navigate the web 169
- soft keys 169

Mode

call answer 119

Multimedia 129

Music

downloading 132

managing your

music 139

playing with flip

closed 135

playing with flip

open 135

transferring from PC 137

My Music 134

My Name Card 80

N

Navigation key 21

Navigation key

shortcuts 53

New message icon 24

No service indicator 23

Non-Supported Battery 26

Notes and tips 11

Notes, description 12

P

Phone Info 127

Phone Memory Storage 29

Phone Settings 111

Location 112

Shortcut Key 112

Standalone Mode 111

Picture ID 123

PIX Gallery 147

214

PIX messages

rejecting 88

view later 88

Place a call while using

Mobile Web 171

Playlist

creating a playlist 140

editing a playlist 141

Powering off 10

Powering on 10

R

Receive messages in call 88

Receive text messages 82

Receiving PIX/FLIX Messages 87

Removing battery 27

Reset phone 116

Restrict calls 121

Retrieving a Message 82

Return to last menu 52

Reviewing sent 91

Right soft key 20

Ringer ID 123

Roaming

definition 37

options 37

Roaming indicator 22

S

Security

call restriction 121

edit lock code 115

lock phone 114

voice privacy 121

Security settings 113

Send key 21

**Sent, reviewing
messages** 91

Set an alarm 161

Settings 101

backlight 108

banner 107

display settings 106

edit lock code 115

language 112

lock phone 114

My Account 102

resetting your phone 116

ringer settings 103

security settings 113

Tools 102

Shortcut to menus 52

Signal strength icon 22

Silent mode icon 24

Sketch messages 89

Snooze 163

Sounds 103

Alert Sounds 104

Call Sounds 103

Earpiece Volume 105

Keypad Volume 104

Master Volume 103

Power On/Off 105

Service Alerts 105

VibeTonz® 106

Speakerphone Key 21

Speed dial, assigning 79

Standard Limited

Warranty

Standard Limited War-
ranty 204

**Store numbers,
shortcuts** 78

**Storing numbers after a
call** 78

Sync Music 137

T

Take FLIX 148

Take PIX 146

**Text messages,
receiving** 82

Three-touch dialing 79

Tip

find a name 32

Tip, description 12

Tools 102, 155

Alarm Clock 102, 161

Calculator 102, 156

Calendar 102, 158

converter 157

Notepad 102, 165

Stop Watch 102, 164

Tip, calculator 157

view an event 160

Voice Commands 102,
156

World Clock 102, 163

Travel Charger 28

TTY Mode 38, 120

Turning Your Phone On and Off 10

Two-second pause 72

Two-touch dialing 79

U

Understanding Your Phone 13

display screen 21

features of your phone 14

front view of your phone
15

V

V CAST Video

browsing/playing

clips 142

configuring alerts 145

deleting clips 143

description 142

downloading clips 143

Vibrate mode icon 24

Video clips 142

**View an event,
calendar** 160

View PIX Msg Later 88

Voice Call Icon 23

Voice Commands

menu, speech

recognition,

voice commands 39

Voice privacy 121

Voicemail 96

listening to 11

setting up 10

viewing messages 97

voicemail icon 24

VoiceSignal

description 44

digit dial 45

features 44

name dial 46

name lookup 48

open apps 48

phone status 49

send picture 47

send text 46

settings 39

W

Wallpaper 109

Warranty Information 203